Viconics Room Controller

TRC6500 Rooftop Unit (RTU), Heat Pump and Indoor Air Quality (IAQ) Firmware Revision 2.1

Operating Guide





Table of Contents

Safety Information	
Before You Begin	
Section 1	
Introduction	
User and Integrator Screens	
BACnet Integration Guide References	7
HMI Display	
Lights and Blinds	
Enter Setup Screen	
Section 2	
Display Show/Hide Options	
System Mode	
Fan Mode Settings	
AI Eco Mode	
Setpoint Adjustment for Automatic Mode	
Other Functions	
Optional Halo Backlight	
Customizable Color Themes	
Section 3	
AI Eco Configuration	
Device Info	
HVAC Configuration	
Lights and Blinds	
Lua	
My Profile	
Network	
Occupancy	
Preferences	
Service View	
Setpoints	
Terminals	
User Management	
Section 4	
Appendix A: Terminal Correspondence	103
Appendix B: Cybersecurity Checklist	
Appendix C: Standby Screen	109
Appendix D: Notifications	110

Safety Information

Important Information

Read these instructions carefully and inspect the equipment to become familiar with the device before trying to install, operate, service or maintain it. The following special messages may appear throughout this bulletin or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a "Danger" or "Warning" safety label indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.

This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

A DANGER

DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.

A WARNING

WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

A CAUTION

CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTICE

NOTICE is used to address practices not related to physical injury. The safety alert symbol shall not be used with this signal word.

PLEASE NOTE

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Viconics Technologies for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction, installation, and operation of electrical equipment and has received safety training to recognize and avoid the hazards involved.

Before You Begin

Loss of Control

NOTICE

EQUIPMENT DAMAGE

- The designer of any control scheme must consider the potential failure modes of control paths and, for certain critical control functions, provide a means to achieve a safe state during and after a path failure. Examples of critical control functions are emergency stop and over travel stop.
- Separate or redundant control paths must be provided for critical control functions.
- System control paths may include communication links. Consideration must be given to the implications of anticipated transmission delays or failures of the link.¹
- Each implementation of equipment utilizing communication links must be individually and thoroughly tested for proper operation before being placed into service.

Failure to follow these instructions can result in equipment damage.

Electrostatic Discharge

NOTICE

EQUIPMENT DAMAGE

Circuit boards and expansion modules can be damaged by static electricity. Observe the electrostatic precautions below when handling controller circuit boards or testing components.

Observe the following precautions for handling static-sensitive components:

- Keep static-producing materials such as plastic, upholstery, and carpeting out of the immediate work area.
- · Store static-sensitive components in protective packaging when they are not installed.
- When handling a static-sensitive component, wear a conductive wrist strap connected to the component or ground through a minimum of 1 megohm resistance.
- Avoid touching exposed conductors and components.

Failure to follow these instructions can result in equipment damage.

¹ For additional information about anticipated transmission delays or failures of the link, refer to NEMA ICS 1.1 (latest edition), *Safety Guidelines for the Application, Installation, and Maintenance of Solid State Control* or its equivalent.

SECTION 1

Introduction

Introduction

This guide shows the user interface instructions for the TRC6500 Viconics Room Controller firmware **revision** 2.1 for users and integrators.

User and Integrator Screens

The TRC6500 Viconics Room Controller has dynamic screens that show adjustable parameters and read-only status information. Some screens and parameters only show when a corresponding parameter is selected. The Lua selection on the Setup screen only shows if a Lua script is uploaded to the Room Controller.

Refer to the following illustration for a legend of the screen details:



* The Lua settings include generic parameters that do not have a specific function or pre-configured functions. These parameters can be used in custom Lua scripts to store a value. They are also user configurable in their default state, but when assigned a value via a Lua script or via BACnet (Priority 1-16), they become read only (not configurable locally by the user). A lock icon will precede the parameter value to indicate this clearly.

NOTE: When a change is made to a parameter on the Home or Preferences screen and saved (by tapping OK/Save/Connect/ etc.), the value is automatically saved in memory when the next parameter is selected or another screen is opened. This event is true only if a parameter was changed locally on the Room Controller. Making changes through BACnet will not have the same outcome. If changes need to be done remotely through BACnet, use priority 1, 2 or 3, or write to relinquish default (priority 17). Refer to the BACnet Integration Guide for more details on BACnet Priorities.

BACnet Integration Guide References

To simplify cross-referencing between the Operating Guide and the BACnet Integration Guide, BACnet object properties are included in the Parameter Details tables as follows:

- · Object name.
- Instance number and object type prefix. Object type prefixes are described as follows:
 - AI Analog Input
 - AO Analog Output
 - AV Analog Value
 - BI Binary Input
 - BO Binary Output
 - BV Binary Value
 - CSV Comma-Separated Value
 - MSI Multi-State Input
 - MV Multi-State Value
- Binary range values (for BI, BO and BV) and status enumeration (MSI and MV) descriptions.

Parameter Default Value	Significance and Adjustments
Parameter	Parameter oObject name
MV99 om Instance number	Choices: 1=On, 2=Auto, 3=Off Range values and enumeration

HMI Display

The User Human Machine Interface (HMI) is configurable and allows display functions such as Time, Humidity, CO2 levels, Outdoor Temperature and Setpoint to be enabled or disabled by setting various parameters.





Lights and Blinds

The Lights and Blind screens provide an easy to access interface where the occupants can control the lights and blinds in the room. The Room Controller does not control the lights and blinds directly, it must be connected by the Modbus network to a SpaceLogic[™] Room Purpose Controller (RP-C). The RP-C is then be connected to the SpaceLogic[™] Light and Blind Modules. The Room Controller always shows the current state of the Lights and Blinds it controls, and will respond immediately to show the progress of the control changes. Refer to the Application Guide for more information on the Lights and Blinds system architecture.

To revert Lights and Blinds back to factory default values, turn on the Reset Lights and Blinds switch on the Factory Reset setup screen.

To configure Lights and Blinds, refer to the following sections:

- "Factory Reset" on page 27
- "Lights and Blinds" on page 47.

Lights (Main)

To see the main Lights screen, swipe left on the home screen. To return to the home screen, swipe right on the Light screen's header or footer. After the configurable inactivity time, the Lights screen will return back to the home screen.

If there are no lights enabled on the device, the Lights screen will be hidden.

The Lights screen can contain any number of lights, up to a maximum of 8 lights.

Each light has a display name and a status indicator (on/off, dim percentage) to help identify which light the occupant wants to operate.

Each light element has an on-off power button at the right of the element, and a status icon at the left of the element. When pressed, the power button will turn green and the status icon will turn yellow.

Pressing anywhere on the light element (except the power button) will open the light element popup screen, where an on-off power button and a dim slider can be used to control the light. To close the popup screen, press the 'X' button or press outside of the popup.



Parameter Default Value	Significance and Adjustments
Light Command	Light # Cmd
Default value: 0	On-off power button and dim percentage slider control.
AV 300 TO AV 307	Range: 0 to 201
Light Status	Light # Status
Default value: 0	On-off status icon and dim percentage.
AV284 to AV291	Range: 0 to 201

Blinds (Main)

To see the main Blinds screen, swipe left on the home screen, then if lights are enabled, swipe left again on the Light screen's header or footer. To return to the home screen, swipe right on the Blind screen's header or footer, then if lights are enabled, swipe right again on the Light screen's header or footer. After the configurable inactivity time, the Blinds screen will return back to the home screen.

If there are no blinds enabled on the device, the Blinds screen will be hidden.

The Blinds screen can contain any number of blinds, up to a maximum of 8 blinds.

Each blind has a display name and a status indicator (open/close percentage) to help identify which blind the occupant wants to operate.

Each blind element has two control buttons to open and close the blinds at the right of the element, and a status icon at the left of the element. When pressed, the control button will be highlighted and the status icon and the open/close percentage indicator will show the blind's position.

Pressing anywhere on the blind element (except the control buttons) will open the blind element popup screen, where the open/ close buttons and a percentage slider can be used to control the position of the blind. To close the popup screen, press the 'X' button or press outside of the popup.





Parameter Default Value	Significance and Adjustments
Blind Command	Blind # Cmd
Default value: 0	Open-close control buttons and percentage slider control.
AV308 to AV315	Range: 0 to 201
Blind Status	Blind # Status
Default value: 0 AV292 to AV299	Open-close status icon and percentage.
	Range: 0 to 201

Enter Setup Screen



• Tap and hold this area for 3 seconds to enter the set-up mode. When the list of users appears on the screen, tap to select the desired user, then enter the corresponding PIN code. This step is to prevent unauthorized access to the configuration menu parameters.

NOTICE

PIN CODE

If an incorrect PIN code is entered repeatedly, a user profile will be blocked for a configurable period of time.

Failure to follow these instructions may lead to an inability to configure the Room Controller.

Setup

Setup	×		
AI Eco Configuration	>	o	Enable and configure AI Eco settings
Device Info	>	o	Device name, location, model number, firmware version, serial number, and
HVAC Configuration	>	o	Tactory reset HVAC ADR, dehumidifier, inputs, and setpoint configuration
Lights and Blinds	>	o	Enable and configure light and blind settings and display name
Lua	>	o	Lua script, status, and variables
My Profile	>	o	User ID, display name, role, and change PIN
Network	>	o	BACnet MS/TP, Modbus, ZigBee and Wi-Fi network settings (ZigBee network settings appear only if ZigBee feature is available)
Occupancy	>	o	Occupancy configuration and schedule
Preferences	>	o	Preferences for date and time, display, halo, language selection, and time zone
Service View	>	o	Service view for alarms, environment, operating status, and system status
Setpoints	>	o ,	Setpoint configuration
Terminals	>	o	Input and output terminals
User Management	>	o	User list, add users, and settings

SECTION 2

Customized User HMI Display

Display Show/Hide Options

The display can be customized further by changing the information and configuring 2 of the buttons, or simply by hiding them entirely. To hide the option, select disabled for each display setup screen parameter. Refer to "Display" on page 78.



Al Eco Mode Buttons



System Mode



PARAMETER DETAILS

System ModeSystem ModeDefault value: Heat• Off: Heating,MV16• Auto: Room Cboth Heating	
 Cool: Room C Dehumidificat Heat: Room C Dehumidificat Choices: 1=Off, 2 	Cooling and Dehumidification demands are ignored. Controller automatically toggles between Heating and Cooling modes to satisfy and Cooling demands. Dehumidification is allowed. Controller only satisfies Cooling demands; Heating demands are ignored. tion is allowed. Controller only satisfies Heating demands; Cooling demands are ignored. tion is allowed. 2=Auto, 3=Cool, 4=Heat

Fan Mode Settings



The Fan mode settings displayed on the home screen must be configured in the Fan menu tab of the Configuration menu. **PARAMETER DETAILS**

Parameter Default Value	Significance and Adjustments
Fan Mode Default value: Smart	Fan Mode
MV17	Choices: 1=On, 2=Auto, 3=Smart, 4=Low, 5=Medium, 6=High

AI Eco Mode

Dynamic HVAC optimization with AI Eco Mode will automatically optimize energy consumption while maintaining comfort through advanced thermal, energy, and comfort modeling. Unlike traditional systems with fixed schedules, the Room Controller can dynamically adapt to changing conditions with self-regulating setpoints. AI logic can continuously analyze factors like occupancy patterns, indoor temperature, outdoor weather conditions, and humidity levels to make real-time adjustments to HVAC setpoints. Occupants can enable AI Eco Mode by pressing the AI Eco Mode button. Since AI Eco Mode is automatic, the setpoint adjustments are not required and will be replaced with the AI Eco Mode logo and text message. The occupant can turn off AI Eco Mode and return to manual setpoint control by pressing the AI Eco Mode button.

If manual setpoint control is not required, AI Eco Mode can be configured as the default HVAC control setting by disabling the AI Eco Mode button on the Display setup screen.

To enable/disable AI Eco Mode, press the Enable AI Eco Setpoint Control switch on the AI Eco Configuration setup screen. To revert AI Eco Mode back to factory default values, turn on the Reset AI Eco Configuration switch on the Factory Reset setup screen. A Factory Reset will clear all model weights so that the Room Controller doesn't control the zone with the model weights calculated in the previous configuration.

The AI Eco Mode Warnings are used to notify the Integrator that the AI Eco Mode is not configured correctly. When the AI Eco Mode configuration is corrected, the AI Eco Mode Warnings will be removed from the home screen.

To configure AI Eco Mode, refer to the following sections:

- "Al Eco Configuration" on page 20
- "Al Eco Mode Warnings" on page 23
- "Factory Reset" on page 27
- "Display" on page 78



Setpoint Adjustment for Automatic Mode

In automatic mode, setpoint showing at the top of the setpoint bar located directly under the blue line represents the actual occupied cooling setpoint.

The actual setpoint is dependent on the last effective demand (heating or cooling). The setpoint on top of the orange line represents the actual occupied heating setpoint. The differential between the occupied heating and cooling setpoint is defined by the minimum deadband configuration parameter.



Other Functions

Local humidity shows when RH display is enabled on the setup display screen, from the internal onboard sensor selected by the RH sensor parameter on the setup configuration screen.

CO2 shows when CO2 display is enabled on the setup display screen, from the optional CO2 detection sensor module selected by the CO2 source parameter on the setup configuration screen.

Outdoor temperature shows when receiving a valid networked outdoor temperature value.

Room 1422 East Go ppm Pmmon Room Indoor CO₂ [™] 18° Outdoor Temperatu	09:00 Room 1422 East	© 45% ఁౖ 700 ppm ఔ 18°	Room Indoor Humidi Room Indoor CO ₂ Outdoor Temperature
---	-------------------------	------------------------------	--

Optional Halo Backlight

The Viconics Room Controller offers the possibility of projecting a halo light onto the wall behind the device. The halo color will fade in to orange when heating, blue when cooling, and off when on standby. To select the halo option, refer to "Halo" on page 80.



Customizable Color Themes

The Viconics Room Controller offers two main color themes: Light and Dark. To select the color option, refer to "Preferences (Main)" on page 18.



Light

Dark

17

Preferences (Main)

To see the main device Preferences screen, swipe right on the home screen.



Parameter Default Value	Significance and Adjustments
Language Selection	Display Language
Default value: English MV4	Allows the user to choose the main device language. While the default is English and always available, the listed options are defined on the Setup Preferences screen. Refer to "Language Selection" on page 81 for more information.
	Choices: 1=English, and the rest of the selected options
Units	Network Units
Default value: Celsius	Celsius
	Fahrenheit
	Choices: Celsius, Fahrenheit
Theme	Color Theme
Default value: Dark MV2	Allows the user to choose a Light or Dark color theme, which will be applied across all screens. This selection is kept in memory throughout power cycles.
	Choices: 1=Light, 2=Dark

SECTION 3

Integrator Setup Screens

AI Eco Configuration





Parameter Default Value	Significance and Adjustments
Enable AI Eco Mode	AI Eco Mode
Default value: Disabled MV211	Al Eco Mode is an automated and optimized HVAC control system that will replace the manual setpoint control with an Al Eco Mode logo and text message on the home screen, and will automatically optimize the HVAC setpoints based on:
	 Occupied cooling setpoint Occupied heating setpoint Unoccupied cooling setpoint Unoccupied heating setpoint Indoor relative humidity Outdoor temperature
	Note : Although it is recommended to use an outdoor temperature sensor to improve the Al accuracy, Al Eco Mode will still work correctly without one.
	Al Eco Mode is compatible with Automated Demand Response (ADR). When both are enabled, Al Eco Mode will use the setpoints that are modified by ADR.
	For best AI Eco Mode performance, Optimal Setpoint, Optimal Start and Optimal Stop must be enabled.
	This feature is configurable via BACnet and Modbus.
	Refer to "AI Eco Mode" on page 15 for more information.
	Choices: 1=Disabled, 2=Enabled

Parameter Default Value	Significance and Adjustments
Optimal Setpoint	AI Eco Optimal Setpoint
Default value: Disabled MV212	Optimal Setpoint allows for AI-enabled dynamic setpoints based on zone conditions to minimize energy usage while maintaining comfort. When enabled, the Room Controller will automatically optimize the HVAC setpoints.
	When setpoints are not configured correctly, a setpoint warning notification will be displayed in a banner on the top of the home screen. Refer to "AI Eco Mode Warnings" on page 23 for more information.
	When disabled, Optimal Setpoint will not modify the setpoints and the Room Controller will rely on occupant-defined setpoints instead.
	Note: Disabling Optimal Setpoint will not remove the warning notification.
	This feature is configurable via BACnet and Modbus.
	Choices: 1=Disabled, 2=Enabled
Optimal Start	AI Eco Optimal Start
Default value: Disabled MV213	Optimal Start allows for AI-enabled dynamic start time based on zone conditions to modify HVAC setpoints to reach the desired occupied setpoints at schedule start. When enabled, the Room Controller will start controlling the temperature at the latest time possible to minimize energy usage while maintaining comfort.
	When Occupancy configuration and schedule settings are not configured correctly, a schedule warning notification will be displayed in a banner on the top of the home screen. Refer to "AI Eco Mode Warnings" on page 23 for more information.
	When disabled, Optimal Start will not modify the setpoints and the Room Controller will rely on local schedules instead.
	Note: Disabling Optimal Start and Stop will remove the warning notification.
	This feature is configurable via BACnet and Modbus.
	Choices: 1=Disabled, 2=Enabled
Optimal Stop	AI Eco Optimal Stop
Default value: Disabled MV214	Optimal Stop allows for AI-enabled dynamic stop time based on zone conditions to modify HVAC setpoints to reach the desired unoccupied setpoints at schedule stop. When enabled, the Room Controller will stop controlling the temperature at the earliest time possible to minimize energy usage while maintaining comfort.
	When Occupancy configuration and schedule settings are not configured correctly, a schedule warning notification will be displayed in a banner on the top of the home screen. Refer to "AI Eco Mode Warnings" on page 23 for more information.
	When disabled, Optimal Stop will not modify the setpoints and the Room Controller will rely on local schedules instead.
	Note: Disabling Optimal Start and Stop will remove the warning notification.
	This feature is configurable via BACnet and Modbus.
	Choices: 1=Disabled, 2=Enabled

Parameter Default Value	Significance and Adjustments
Verbose Logging	AI Eco Verbose Logging
MV215	Verbose Logging adds information to the system logs that is used to better understand model performance. When enabled, the following information will be printed to the system logs:
	 Model parameters: Example: "clear:0, control:1, comfort:1, start:1, stop:1, cl_lim:28.0, cl_occ:27.5, cl_unocc:26.7, ht_lim:15.5, ht_occ:26.0, ht_unocc:16.7" TRC parameters: Example: "device:1741036804 room_temp:23.7, humidity:0.14, cool:0, demand:1.00" Occupancy details: Example: "occ_time:1741036804 duration:9600s" Weather details: Example: "weather:1741036804 outdoor_temp:20.0" Al Eco model version: Example: "Model version:2.0.0" Model weights: Example: "a[0]:0.590550, b[0]:0.009562, a[1] b[5]:0.00000" Control predictions for next 4 hours: Example: "1741037430 temp:22.9, cool:0, cl_ctl:28.0, cl_cft:28.0, ht_ctl:26.7, ht_cft:26.7, occ:1, start:0, stop:0, demand:1.0" Effective heat and cool setpoints: Example: "Effective sp[0]: 28.0/26.7"
	When disabled, the Room Controller will not log any additional information in the system logs.
	This feature is only accessible via BACnet and Modbus.
	Choices: 1=Disabled, 2=Enabled
AI Model Version	Al Model Version
Read Only CSV61	Displays the current AI model version.
	Display Readings: 0 to 16 characters

998-22961312-3-en

AI Eco Mode Warnings

The AI Eco Mode Warnings are used to notify the Integrator that the AI Eco Mode is not configured correctly. When the AI Eco Mode configuration is corrected, the AI Eco Mode Warnings will be removed from the home screen. The corrections must be done before placing the Room Controller into service. The AI Eco Mode Warnings are also displayed via the BACnet and Modbus networks. The AI Eco Mode Warnings will be translated into the language selected on the main Preferences screen.

Note: If the Notifications parameter is set to Disabled or Custom Only, then the AI Eco Mode Warnings will not be displayed on the home screen. Make sure that the Notifications parameter is set to All. Refer to "Display" on page 78 for more information.



Parameter Default Value	Significance and Adjustments
AI Eco Schedule Warning	AI Eco Schedule Warning
Read Only BV11	When Occupancy configuration and schedule settings are not configured correctly, a schedule warning notification will be displayed in a banner on the top of the home screen: "Warning: Al Eco mode enabled without local schedule".
	Make sure that the Occupancy Command is set to Local Occupancy, the Occupancy Source is set to Schedule, and that the Occupancy Schedule is set correctly.
	If your Occupancy Configuration requires other settings than the above, then the AI Eco Mode Optimal Start and Optimal Stop must be disabled.
	Refer to "Occupancy" on page 72 for more information.
	Display Readings: 0=Off, 1=On

Parameter Default Value	Significance and Adjustments				
AI Eco Setpoint Warning	AI Eco Setpoint Warning				
BV12	When setpoints are not configured correctly, a setpoint warning notification will be displayed in a banner on the top of the home screen: "Warning: AI Eco paused (setpoints out of range)".				
	To use AI Eco Mode, the following setpoints must be between 60.0°F to 82.0°F (15.5°C to 28.0°C):				
	 Occupied Cooling Setpoint Occupied Heating Setpoint Unoccupied Cooling Setpoint Unoccupied Heating Setpoint 				
	If your HVAC configuration requires these setpoints to be out of range of the temperatures above, then AI Eco Mode must be disabled.				
	Refer to "Setpoints" on page 93 for more information.				
	Display Readings: 0=Off, 1=On				
AI Eco Dehumidification	AI Eco Dehumidification Warning				
Warning Read Only BV13	Al Eco Mode is not compatible with dehumidification, a warning notification will be displayed in a banner on the top of the home screen: "Warning: Dehumidification not recommended with Al Eco".				
	Refer to "Dehumidifier" on page 31 for more information.				
	If your HVAC configuration requires dehumidification, then AI Eco Mode must be disabled.				
	Display Readings: 0=Off, 1=On				

Device Info

<	Device Info	
	Device Name	
	TRCnn00-FL23453TRC00016	
	Location	
	Model Number	
	SXWTRCnn00BccX	
	Part Number SXWTRCnn00BccX	
	Firmware Version 2.1.0-170-204ea093b	
	Serial Number FL23453TRC00016	

Parameter Default Value	Significance and Adjustments
Device Name	Device Name
SerialNumber CSV4	The Device Name (BACnet name) is a combination of the short SKU and the serial number. The BACnet name can be changed via the BACnet front end, and the new name appears on the above screen.
	Example: TRCnn00-MT-2023-W28-1-FL23453TRC00016
	Range: 5 to 49 characters (a-z, A-Z, 0-9, @~+=^<>,.1/2:;,*'`, and spaces)
Location	Location
CSV35	Read/write value shows the location of the device as configured in BACnet, Lua, on screen via the keyboard, etc.
	NOTE: The information is kept across power cycles. It is also important to note that there is no text wrapping on the Home screen; the Room Controller displays the characters that fit on one line.
	Range: 0 to 49 characters (a-z, A-Z, 0-9, @~+=^<>,.1/2:;*'`, and spaces)
Model Number	Model Number
Read Only	Read Only value shows the device SKU:
	 TRC6500BccX-VC: Viconics Room Controller for Rooftop Unit (RTU), Heat Pump and Indoor Air Quality (IAQ) Systems with Passive Infrared (PIR). TRC6500BccW-VC: Viconics Room Controller for Rooftop Unit (RTU), Heat Pump and Indoor Air Quality (IAQ) Systems with Passive Infrared (PIR), ZigBee and Wi-Fi.

Parameter Default Value	Significance and A	djustment	ts						
Part Number Read Only	Part Number								
	Read Only value shows the device variant:								
	Part Number	BACnet/ MSTP or Modbus RTU	RF (Wi-Fi + Zigbee)	RH Sensor	Passive IR Sensor	Proximity Sensor	Halo Light	Color	Region
	TRC6500B11X-VC	٠		٠	٠			White	Global
	TRC6500B11W-VC	•	•	•	•	•	•	White	Global (except NAM)
	TRC6500B11WA-VC	•	•	٠	٠	٠	•	White	North America
	TRC6500B00X-VC	٠		٠	٠			Black	Global
	TRC6500B00W-VC	•	•	•	•	•	•	Black	Global (except NAM)
	TRC6500B00WA-VC	•	•	•	•	•	•	Black	North America
Firmware Version Read Only CSV5	Firmware Version Read Only value sho Upgrading to a news	ws the firm er Firmwar	nware ver e version	sion curre deletes th	ently installe	ed on the R Firmware	loom C	ontrolle	r.
Serial Number Read Only	Serial Number Read Only value sho	ws a string	g of chara	cters tha	t identifies a	a single spe	ecimen	of proc	luct.
Factory Reset	Refer to "Factory Res	set" on pag	ge 27 for r	nore infor	mation.	_ '			

Factory Reset



Parameter Default Value	Significance and Adjustments
Factory Reset	Factory Reset
	and reverts back to factory default values for:
	 Reset All Reset Al Eco Configuration Reset HVAC Configuration Rest Lights and Blinds Reset Log Files Reset Lua Scripts Reset Network Configuration Reset User Data Reset System Data
	NOTE: The device may restart during this process.

HVAC Configuration

Refer to "Setup" on page 11 to see the accessible menus for the configuration screens.

<	HVAC Configuration	Â
	Application Rooftop Unit	~
	ADR	>
	Dehumidifier	>
	Economizer	>
	Indoor Air Quality	>
	Inputs	>
	Rooftop Unit	>
	Setpoint Configuration	>

 HVAC Configuration 	
Application Heat Pump	\sim
ADR	>
Dehumidifier	>
Economizer	>
Heat Pump	>
Indoor Air Quality	>
Inputs	>
Setpoint Configuration	>

Parameter Default Value	Significance and Adjustments
Application	Application
Default value: Rooftop Unit MV119	Used to indicate the HVAC application of this device.
	Choice: 1=Rooftop Unit, 2=Heat Pump
ADR	Refer to "ADR (Automated Demand Response)" on page 29 for more information.
Dehumidifier	Refer to "Dehumidifier" on page 31 for more information.
Economizer	Refer to "Economizer" on page 32 for more information.
Heat Pump	The Heat Pump screen is displayed when Application is set to Heat Pump. Refer to "Heat Pump" on page 34 for more information.
Indoor Air Quality	Refer to "Indoor Air Quality" on page 38 for more information. The IAQ screen is displayed when Economizer is enabled.
Inputs	Refer to "Inputs" on page 39 for more information.
Rooftop Unit	The Rooftop Unit screen is displayed when Application is set to Rooftop Unit. Refer to "Rooftop Unit" on page 42 for more information.
Setpoint Configuration	Refer to "Setpoint Configuration" on page 45 for more information.



Parameter Default Value	Significance and Adjustments				
Automated Demand Response	ADR Permission Indicates if this feature is enabled or disabled.				
Default value: Disabled MV157	Choices: 1=Disabled, 2=Enabled				
Load Shedding Setpoint Offset	ADR Setpoint Offset - Load Shedding				
Default value: 4°F (2°C)	Used to change the effective setpoints in occupied, standby and unoccupied modes.				
AV280	For example, when Load Shedding Status is active and Room Controller is in occupied mode:				
	The cooling setpoint is calculated as follows: Occupied cooling setpoint = occupied cooling setpoint + Load shedding offset.				
	The heating setpoint is calculated as follows: Occupied heating setpoint = occupied heating setpoint - Load shedding offset.				
	Range: 1°F to 10°F (0.5°C to 5.5°C)				
Load Shedding Utility	ADR Utility Signal - Load Shedding				
Default value: Off Read Only	Sets the request to initiate Load Shedding. This demand can only be set through BACnet by the local Utility company.				
BV80	 Inactive (off): No Load Shedding Demand is received or the Shedding demand is disabled. Active (on): Received the Load Shedding Demand or received the signal to activate Load shedding. 				
	This parameter resets to its default value after a power cycle.				
	Display Readings: 0=Off, 1=On				

Parameter Default Value	Significance and Adjustments
Load Shedding Status	ADR Status - Load Shedding
Default value: Off Read Only BV81	Displays the status of the Load Shedding Demand, whether it is active (On) or not (Off).
	The Load Shedding status is On when the Permission is On, Shed demand is On, and the Shed Override is Off
	Inactive (off): Load Shedding Demand is not activated
	Active (on): Load Shedding Demand is activated.
	This parameter resets to its default value after a power cycle.
	Display Readings: 0=Off, 1=On
Load Shedding Override	ADR Override - Load Shedding
Default value: Off Read Only BV82	Displays whether the user disabled the ADR request by the utility company. When the demand shed is applied, the user can override the ADR settings from its original setpoints settings.
DV02	 Inactive (off): Allows shed load demand request from utility company (setpoint will change according to shed offset)
	 Active (on): Rejects or cancels shed load demand request from utility company (setpoints remain the same).
	Display Readings: 0=Off, 1=On
Pricing Setpoint Offset	ADR Setpoint Offset - Pricing
Default value: 4°F (2°C) AV281	Used to configure the difference between the pricing setpoint and the actual measurement.
	Range: 1°F to 10°F (0.5°C to 5.5°C)
Pricing Utility Signal	ADR Utility Signal - Pricing
Default value: Off Read Only	Indicates the grid is approaching its limit, dynamic pricing is high, and it is recommended to reduce energy usage to save money and reduce the load on the grid.
5400	This feature is configurable via BACnet and Modbus.
	Display Readings: 0=Off, 1=On
Pricing Status	ADR Status - Pricing
Default value: Off Read Only BV84	Indicates if there is an ADR Status Pricing point. This feature resets to its default inactive on power cycle.
	It is active when:
	 ADR is enabled Pricing Utility Signal is active Pricing Override is inactive
	Display Readings: 0=Off, 1=On
Pricing Override	ADR Override - Pricing
Default value: Off Read Only BV85	Indicates if the ADR Pricing Override is active or not. This feature resets to its default inactive on power cycle.
	Configurable via the home screen interface when ADR is enabled, and ADR Pricing Utility Signal is active. Reverts to its default value when ADR Pricing Utility Signal changes from active to inactive.
	Display Readings: 0=Off, 1=On

30

Dehumidifier



Parameter Default Value	Significance and Adjustments				
Dehumidification	Dehumidification Enabled				
Default value: Disabled	ndicates if this feature is enabled or disabled.				
MV13	Choices: 1=Disabled, 2=Enabled				
Dehumidification Setpoint	Dehumidification Setpoint				
Default value: 50% AV71	Jsed when Dehumidification is enabled. Used to define the target humidity level for the dehumidification sequence.				
	Range: 30% to 95%				
Dehumidification	Dehumidification Hysteresis				
Hysteresis Default value: 5% RH AV72	Used as a hysteresis around the Dehumidification Setpoint to avoid fast toggling of the equipment when the humidity is around the setpoint.				
	Example: If setpoint is 50% and hysteresis is 5%, the dehumidifier will:				
	Turn on when the humidity rises above 50%Turn off when the humidity falls below 45%				
	Range: 2% to 20% RH				
Dehumidification Status	Dehumidification Status				
Default value: Off Read Only BV38	Used when Dehumidification is enabled. Defines whether dehumidification is currently active or inactive. This can be used to balance smaller reheat loads installed in regard to the capacity of the cooling coil.				
	Display Readings: 0=Off, 1=On				

Economizer



Parameter Default Value	Significance and Adjustments
Economizer Default value: Off MV72	 Economizer Configuration Enables or disables the economizer functionality. Off: Economizer deactivated On: Economizer activated
Economizer Minimum	Economizer Minimum Position
Position Default value: 0% AV78	Minimum Outside Air damper position when Room Controller is in Occupied, Standby or Override mode and Fan status is ON. If Room Controller is Unoccupied mode and/or the Fan is Off, Outside Air damper position goes to 0%. Range : 0% to 100%
Economizer Maximum	Economizer Maximum Position
Position Default value: 100% AV81	Maximum Outside Air damper position when Room Controller is in Occupied, Standby or Override mode and Fan status is ON. This is valid only for Economizer, CO2 and Airflow functions.
	Range: 0% to 100%
Changeover Setpoint Default value: 55°F (13°C) AV95	Changeover Setpoint
	from mechanical (compressor) to free cooling (economizer).
	Range: 14°F to 70°F (-10°C to 21°C)
Supply Air Temperature Setpoint Default value: 55°F (12°C) AV94	Supply Air Temperature Setpoint
	Free cooling supply air setpoint when economizer mode is enabled.
	Range: 50 to 90°F (10.0 to 32.0°C)

Parameter Default Value	Significance and Adjustments
Mechanical Cooling Allowed	Mechanical Cooling Allowed
Default value: Off	Allows operation of mechanical cooling if free cooling (economizer) cannot maintain the cooling
MV79	setpoint.
	 Off: Applies when the mixed air temperature sensor is installed after the mechanical cooling refrigeration coils. In this case, mechanical cooling never operates at the same time as free cooling. On: Applies when the mixed air temperature sensor is installed before the mechanical
	cooling refrigeration coils in the mixing plenum. In this case, mechanical cooling is allowed when the free cooling (economizer operation) cannot maintain the cooling setpoint.
	Choices: 1=Off, 2=On

Heat Pump

The Heat Pump screen is displayed when Application is set to Heat Pump on the HVAC Configuration screen.



Parameter Default Value	Significance and Adjustments
Number of Heating Stages Default value: 1 stages AV87	Number of Heating Stages
	Sets number of Heating Stages applicable to 2 stage models only.
	 0: Modulating Heat: AO3 modulating 0-10Vdc output is used for Heating. DO5 is disabled. 1: Auxiliary Heat: DO5 is used. AO3 is disabled.
	Choices: 0: Modulating Heat, 1: Auxiliary Heat
Number of Compressor Stages Default value: 2 stages AV75	Number of Cooling Stages
	Sets number of Cooling Stages.
	 1 Stage: Only Y1 (DO3) terminal is used. Y2 (DO2) is disabled. 2 Stages: Both Y1 (DO3) and Y2 (DO2) terminals are used in sequence.
	Choices: 1 or 2 stages
Reversing Valve Operation Default value: O MV117	Reversing Valve Operation
	Heat pump reversing valve operation.
	 O: Active for Cooling: Energize valve in cooling operation. B: Active for Heating: Energize valve in heating operation.
	Choices: 1=O, 2=B
Compressor Interlock Default value: Off MV118	Compressor - auxiliary interlock
	Sets the operation and interaction mode of the heat pump with the auxiliary heat.
	 Off: In Heating mode, if the heat pump is not able to satisfy the heating setpoint, the auxiliary heat gets energized at the same time as the heat pump stage. Typically applies when the air handler heat pump coil is installed before the auxiliary heat (all electric systems). On: In Heating mode, if the heat pump is not able to satisfy the heating setpoint, the auxiliary heat gets energized and the heat pump is cut off. Typically applies when the air handler heat pump coil is installed after the auxiliary heat (add on systems) There is a 2 minute delay to restart the heat pump when the auxiliary heat is shut down.
	Choices: 1=Off, 2=On

Parameter Default Value	Significance and Adjustments
Anti Short Cycle Time Default value: 2 min AV86	Anti Short Cycle Time
	Minimum On time and minimum Off time of operation time for stages.
	IMPORTANT: anti-short cycling can be set to 0 minutes for equipment that possess their own anti cycling timer. Do not use this value unless the equipment is equipped with an internal timer. Failure to do so can damage the equipment.
	Range: 0 to 5 min
Cooling Cycles Per Hour	Cooling CPH
Default value: 4 CPH AV85	CPH is used to "modulate" On/Off outputs controlling equipment such as compressors. When the Room Temperature is within the Proportional Band, the output performs 3 or 4 CPH. A higher CPH represents a higher accuracy of control at the expense of wearing mechanical components faster.
	NOTE : The CPH does not limit the number of Cycles Per Hour. It is limited by the "Anti short cycle" parameter. 4 CPH is typical for Rooftop applications.
	Range: 3 to 4 CPH
Heating Cycles Per Hour	Heating CPH
Default value: 4 CPH AV84	CPH is used to "modulate" On/Off outputs controlling equipment such as compressors. When the Room Temperature is within the Proportional Band, the output performs 3 to 8 CPH. A higher CPH represents a higher accuracy of control at the expense of wearing mechanical components faster.
	For multi-stage models, heat CPH applies to W1 (DO5) & W2 (DO6). A CPH value between 6 - 8 is recommended for applications with electric heating. For gas applications set CPH to 4 and for oil applications set CPH to 3.
	Range: 3 to 8 CPH
Room Frost Protection	Room Frost Protection
Default value: Off MV55	If the Room Temperature drops below 42°F (5.6°C), the Fan and the Heat will be activated until the Room Temperature rises over 42°F (5.6°C).
	 Off: No room frost protection On: Room frost protection enabled in all system modes at 42°F (5.6°C).
	Frost protection is enabled even if System mode is 'Off'.
	Choices: 1=Off, 2=On
Heating Lockout from	Heating Lockout from Outside Air Temperature
Outside Air Temperature Default value: 120°F (49°C) AV91	Disables mechanical heating operation when Outdoor Temperature is higher than the "Heating Lockout" value. The Outdoor Temperature value could be received from a sensor connected directly to the Room Controller (UI23) or via a BACnet front end (network).
	Range: -15°F to 120°F (-26°C to 49°C)
Cooling Lockout from Outside Air Temperature Default value: -40°F (-40°C) AV93	Cooling Lockout
	Disables mechanical cooling operation when Outdoor Temperature is lower than the "Cool Lockout" value. The Outdoor Temperature value could be received from a sensor connected directly to the Room Controller (UI23) or via a BACnet front end (network).
	The Economizer functionality (Free-cooling) can still be enabled during the Cooling Lockout.
	Range: -40°F to 95°F (-40°C to 35°C)
High Balance Point Default value: 90°F (32°C) AV82	High Balance Point
	In Heating or Auto mode, it is the outside air temperature value at which the auxiliary heat is cut off. If the temperature exceeds this value, only the heat pump is used to maintain the heating setpoint.
	NOTE : Function enabled only if outside air temperature value is populated (not -40°F/°C). The Outdoor Temperature value could be received from a sensor connected directly to the Room Controller or via a BACnet front end (network).
	Range: 34°F to 90°F (1°C to 32°C)

Parameter Default Value	Significance and Adjustments
Low Balance Point	Low Balance Point
Default value: -12°F (-24.5°C) AV83	In Heating, Cooling or Auto mode, it represents the outside air temperature value at which the heat pump operation will be cut off. If the temperature falls below this value, only the auxiliary heat is used to maintain the heating setpoint.
	NOTE : Function enabled only if outside air temperature value is populated (not -40°F/°C). The Outdoor Temperature value could be received from a sensor connected directly to the Room Controller or via a BACnet front end (network).
	Range: -40°F to 30°F (-40°C to -1°C)
Comfort or Economy Mode	Comfort or Economy Mode
Default value: Comfort	Sets the operation and interaction mode of the heat pump with the auxiliary heat.
MV116	 Comfort: In Heating mode, if the heat pump is not able to satisfy the heating setpoint, the auxiliary heat gets energized to satisfy the same heating setpoint. Economy: In Heating mode, if the heat pump is not able to satisfy the heating setpoint, the auxiliary heat gets energized to satisfy only when the temperature drops 2.0°F (1.1°C) below the heating setpoint. Selecting economy mode adds a deadband between the heat pump & auxiliary heat in heating mode. The actual temperature maintained will be lower than the true heating setpoint to maximize the heat pump operation. When the outdoor air
	heat maintains the true heating setpoint alone.
	Choices: 1=Comfort, 2=Economy
Minimum Supply Heat Default value: 64°F (18.0°C)	Minimum Supply Heat Displayed when Number of Heating Stages = 0: Modulating Heat.
	Range: 50°F to 72°F (10°C to 22°C)
Supply Heat Lockout	Supply Heat Lockout
Default value: 32°F (0.0°C)	Displayed when Number of Heating Stages = 0: Modulating Heat.
AV98	Range: -15°F to 120°F (-26°C to 48.5°C)
Supply Temperature High	Supply Temperature High Limit
Limit	Supply air high temperature value at which the heating stages get locked out.
AV99	Range: 70°F to 150°F (21°C to 66°C)
Supply Temperature Low	Supply Temperature Low Limit
Limit Default value: 45°F (7°C) AV20	Supply air low temperature value at which the cooling stages get locked out.
	Range: 35°F to 65°F (2.0°C to 18.0°C)
Fan Control in Heating Mode Default value: Enabled MV95	 Fan Control in Heating Mode Enabled: Room Controller always controls the fan (terminal DO4: G Fan). Valid for On or Auto fan mode. Forced Off: Fan (terminal DO4: G Fan), when heating stages (terminals W1 (DO5) & W2 (DO6)) are solicited, will not be energized. The fan is controlled by the equipment fan limit control. Valid only for Auto fan mode. On fan mode leaves the fan always on. For multi-stage models, fan control applies to W1 (DO5) & W2 (DO6). Choices: 1=Enabled, 2=Forced Off
Fan Delay	Fan Delay
Default value: On MV12	 Off: Fan delay not operational. On: Fan mode will leave the fan always on and extends fan operation by 60 seconds after the call for heating or cooling ends. Valid only for Auto fan mode.
	Choices: 1=Off, 2=On
Parameter Default Value	Significance and Adjustments
--	---
Proportional Band	Proportional Band
Default value: 3°F (2°C) AV65	Adjusts proportional band used by Room Controller PI control loop.
	NOTE: Default value of 3 gives satisfactory operation in most normal installation cases. The use of a superior proportional band different than the factory value is normally warranted in applications where Room Controller location is problematic and leads to unwanted cycling of the unit. A typical example is a wall mounted Room Controller installed between return and supply air feeds and is directly influenced by the supply air stream of unit.
Power-up Delay	Power-up Delay
Default value: 10 seconds AV76	On initial power up of the Room Controller there is a delay before any operation is authorized (fan, cooling or heating). This can be used to sequence the start up of multiple Room Controllers in one location. Range: 10 to 120 seconds (Resolution: 1 second)

Indoor Air Quality

The IAQ screen is displayed when Economizer is enabled.



Parameter Default Value	Significance and Adjustments
Minimum CO2 Level Default value: 800 ppm AV23	Minimum CO2 Defines the minimum comfort level for CO_2 . When the CO_2 level is above this value, the fresh air damper will be (progressively) opened to reduce the CO_2 level.
	Range: 0 to 4800 ppm
Maximum CO2 Level Default value: 1200 ppm AV24	Maximum CO2Defines the maximum comfort level for CO_2 .When the CO_2 level is above this value, the fresh air damper will be opened to the maximum position to reduce the CO_2 level.Range: 200 to 5000 ppm
Fresh Air Range	Fresh Air Range Upper Limit
Default value: 0 cfm AV96	Sets the upper limit (reading range) of the "airflow measuring station" (e.g., for 0~1,000 CFM station, setting "FA Range" to 1,000).
	Range: 0 to 20000 ctm
Minimum Fresh Air Volume Default value: 0 cfm AV21	Minimum Fresh Air Displayed when Fresh Air Range is greater than 0.
Maximum Fresh Air Volume Default value: 0 cfm AV22	Maximum Fresh Air Displayed when Fresh Air Range is greater than 0.
	Range: 0 to 20000 cim

Inputs



Parameter Default Value	Significance and Adjustments
UI1 Config Default value: None MV46	 UI1 Configuration None: No function will be associated with the input. Input can be used for remote network monitoring. Rem NSB: Remote night setback (NSB) timer clock input. The scheduling gets set as per the binary input and provides low-cost setback operation via a dry contact. Motion NO and Motion NC: Advanced PIR occupancy functions using a Normally Open (NO) or Normally Closed (NC) remote PIR motion sensor. Window: Forces the system to disable any current heating or cooling action by the Room Controller when the window is open. Fan Lock: Forces the system to disable any current heating or cooling action by the Room Controller when the (G) Fan output is activated, but the Fan Lock input is not activated after 10 seconds.
	Choices: 1=None, 2=Rem NSB, 3=Motion NO, 4=Motion NC, 5=Window, 6=Fan Lock
UI2 Config Default value: None MV47	 UI2 Configuration None: No function associated with input. Door Dry: Room Controller goes to standby mode when door is opened then closed followed by no presence detection for the next 10 seconds if the local PIR is used in this application. The Occupancy command must be set to Local Occupancy and Occupancy Source must be set to Motion. Override: A closed contact forces the Room Controller to go in occupied mode. An open contact keeps the current occupancy mode. Filter: backlit flashing filter alarm shows on the Room Controller screen when input is energized. Service: backlit flashing Service alarm shows on Room Controller screen when input is energized. NOTE: When the Room Controller is in unoccupied mode, touching the screen sets the Room Controller to Override mode for defined time period, and uses the Occupied Cooling and Heating setpoints. Choices: 1=None, 2=Door Dry, 3=Override, 4=Filter, 5=Service

Parameter Default Value	Significance and Adjustments
UI3 Config Default value: None MV49	 UI3 Configuration None: No function associated with input; however, input can be used for remote network monitoring.
	 CO₂: Using the CO₂ level measured by a wired CO₂ sensor (0~2000 ppm = 0~10 Vdc), the Outside Air damper (Econo) will modulate between "Economizer Minimum Position" to "Economizer Maximum Position" following the "Minimum CO₂" and "Maximum CO₂" setpoints.
	Choices: 1=None, 2=CO ₂
Room Temperature Sensor	Room Temperature Sensor
Default value: Wired MV150	Sets the source of the indoor room temperature for Room Controller. Then user can designate either the Room Controller itself, a wired remote sensor, or any of the paired wireless devices* that support temperature to function as the source for the room temperature.
	 Wired: Sets the thermistor connected to U4 (RS) as the source to report room temperature. Internal: Sets the Room Controller as the source for the room temperature. WL 1 to WL 20: Sets the selected Zigbee wireless device as the source for the room temperature. Only one device can be selected.
	NOTE: If a wired or wireless sensor is selected while it is offline, then the Room Controller internal sensor will be the source for the temperature measurement.
	Choices: 1=Wired, 2=Internal, 3=Wireless Sensor 1, 4=Wireless Sensor 2, 5=Wireless Sensor 3, 6=Wireless Sensor 4, 7=Wireless Sensor 5, 8=Wireless Sensor 6, 9=Wireless Sensor 7, 10=Wireless Sensor 8, 11=Wireless Sensor 9, 12=Wireless Sensor 10, 13=Wireless Sensor 11, 14=Wireless Sensor 12, 15=Wireless Sensor 13, 16=Wireless Sensor 14, 17=Wireless Sensor 15, 18=Wireless Sensor 16, 19=Wireless Sensor 17, 20=Wireless Sensor 18, 21=Wireless Sensor 19, 22=Wireless Sensor 20
Room Temperature Sensor	Calibrate Room Temperature Sensor
Calibration Default value: 0 °F (-17.8°C) AV7	Room temperature sensor calibration. Offset can be added or subtracted to actual displayed room temperature.
	Range: -5°F to 5°F (-2.5°C to +2.5°C) – Resolution: 1°F/0.5°C
Outside Temperature	Calibrate Outside Temperature Sensor
Sensor Calibration Default value: 0 °F (-17.8°C) AV74	Calibrates the temperature value.
	Range: -5°F to 5°F (-2.5°C to +2.5°C) – Resolution: 1°F/0.5°C
Relative Humidity Sensor	Relative Humidity Sensor
MV154	Sets the source of the indoor room humidity. This parameter allows the user to designate either the Room Controller or any of the paired wireless devices* that support humidity to function as the source for the room humidity.
	 None: Relative Humidity source disabled. Internal: Sets the Room Controller as the source for the room humidity. WL 1 to WL 20: Sets the selected ZigBee wireless device as the source for the room humidity. Only one device can be selected.
	NOTE: None is kept as an option here to allow humidity to be supplied via BACnet, Modbus or Lua.
	Choices: 1=None, 2=Internal, 3=Wireless Sensor 1, 4=Wireless Sensor 2, 5=Wireless Sensor 3, 6=Wireless Sensor 4, 7=Wireless Sensor 5, 8=Wireless Sensor 6, 9=Wireless Sensor 7, 10=Wireless Sensor 8, 11=Wireless Sensor 9, 12=Wireless Sensor 10, 13=Wireless Sensor 11, 14=Wireless Sensor 12, 15=Wireless Sensor 13, 16=Wireless Sensor 14, 17=Wireless Sensor 15, 18=Wireless Sensor 16, 19=Wireless Sensor 17, 20=Wireless Sensor 18, 21=Wireless Sensor 19, 22=Wireless Sensor 20
Relative Humidity Sensor	Calibrate Humidity Sensor
Calibration Default value: 0% AV8	Offset that can be added or subtracted to actual displayed humidity.
	Range: -15% to 15% (Resolution: 1%)

Parameter Default Value	Significance and Adjustments
CO ₂ Sensor Source	CO ₂ Source
MV155	Sets the source of the indoor CO_2 . This parameter allows the user to select the embedded CO_2 detection sensor or to disable the feature.
	 None: CO₂ source disabled. Local: Sets the embedded CO₂ detection sensor as the source for the room CO₂.
	Choices: 1=None, 2=Local, 3=Wireless Sensor 1, 4=Wireless Sensor 2, 5=Wireless Sensor 3, 6=Wireless Sensor 4, 7=Wireless Sensor 5, 8=Wireless Sensor 6, 9=Wireless Sensor 7, 10=Wireless Sensor 8, 11=Wireless Sensor 9, 12=Wireless Sensor 10, 13=Wireless Sensor 11, 14=Wireless Sensor 12, 15=Wireless Sensor 13, 16=Wireless Sensor 14, 17=Wireless Sensor 15, 18=Wireless Sensor 16, 19=Wireless Sensor 17, 20=Wireless Sensor 18, 21=Wireless Sensor 19, 22=Wireless Sensor 20

Rooftop Unit

The Rooftop Unit screen is displayed when Application is set to Rooftop Unit on the HVAC Configuration screen.



Parameter Default Value	Significance and Adjustments
Number of Heating Stages	Number of Heating Stages
Default value: 2 stages	Sets number of Heating Stages applicable to 2 stage models only.
AV87	 0 Stages: Only (UO11) modulating 0-10Vdc output is used for Heating. W1 & W2 are disabled. 1 Stage: Only W1 (D5) terminal is used. W2 is disabled. 2 Stages: Both W1 (D5) and W2 (A1/D6) terminals are used in sequence.
	Choices: 0: Modulating Heat, 1 or 2 stages
Number of Cooling Stages	Number of Cooling Stages
Default value: 2 stages	Sets number of Cooling Stages.
	 1 Stage: Only Y1 (D3) terminal is used. Y2 is disabled. 2 Stages: Both Y1 (D3) and Y2 (D2) terminals are used in sequence.
	Choices: 1 or 2 stages
Anti Short Cycle Time	Anti Short Cycle Time
Default value: 2 min AV86	Minimum On time and minimum Off time of operation time for stages.
	IMPORTANT: anti-short cycling can be set to 0 minutes for equipment that possess their own anti cycling timer. Do not use this value unless the equipment is equipped with an internal timer. Failure to do so can damage the equipment.
	Range: 0 to 5 minutes
Cooling Cycles Per Hour	Cooling Cycles Per Hour
Default value: 4 CPH AV85	CPH is used to "modulate" On/Off outputs controlling equipment such as compressors. When the Room Temperature is within the Proportional Band, the output performs 3 or 4 CPH. A higher CPH represents a higher accuracy of control at the expense of wearing mechanical components faster.
	NOTE: The CPH does not limit the number of Cycles Per Hour. It is limited by the "Anti short cycle" parameter. 4 CPH is typical for Rooftop applications.
	Range: 3 to 4 CPH

Parameter Default Value	Significance and Adjustments
Heating Cycles Per Hour	Heating Cycles Per Hour
Default value: 4 CPH AV84	CPH is used to "modulate" On/Off outputs controlling equipment such as compressors. When the Room Temperature is within the Proportional Band, the output performs 3 to 8 CPH. A higher CPH represents a higher accuracy of control at the expense of wearing mechanical components faster.
	For multi-stage models, heat cph applies to W1 & W2. A CPH value between
	6 - 8 is recommended for applications with electric heating. For gas applications set CPH to 4 and for oil applications set CPH to 3.
	Range: 3 to 8 CPH
Room Frost Protection	Room Frost Protection
Default value: Off MV55	If the Room Temperature drops below 42°F (5.6°C), the Fan and the Heat will be activated until the Room Temperature rises over 42°F (5.6°C).
	Off: No room frost protection
	• On: Room frost protection enabled in all system modes at 42°F (5.6°C).
	Frost protection is enabled even if System mode is 'Off'.
	Choices: 1=Off, 2=On
Heating Lockout from	Heating Lockout from Outside Air Temperature
Outside Air Temperature Default value: 120°F (49°C) AV91	Disables mechanical heating operation when Outdoor Temperature is higher than the "Heating Lockout" value. The Outdoor Temperature value could be received from a sensor connected directly to the Room Controller (UI23) or via a BACnet front end (network).
	Range: -15°F to 120°F (-26°C to 49°C)
Cooling Lockout from	Cooling Lockout from Outside Air Temperature
Outside Air Temperature Default value: -40°F (-40°C) AV93	Disables mechanical cooling operation when Outdoor Temperature is lower than the "Cool Lockout" value. The Outdoor Temperature value could be received from a sensor connected directly to the Room Controller (UI23) or via a BACnet front end (network).
	The Economizer functionality (Free-cooling) can still be enabled during the Cooling Lockout.
	Range: -40°F to 95°F (-40°C to 35°C)
Minimum Supply Heat	Minimum Supply Heat
Default value: 64°F (18.0°C) AV97	Displayed when Number of Heating Stages = 0: Modulating Heat.
	Range: 50°F to 72°F (10°C to 22°C)
Supply Heat Lockout	Supply Heat Lockout
Default value: 32°F (0.0°C)	Displayed when Number of Heating Stages = 0: Modulating Heat.
Av 90	Range: -15°F to 120°F (-26°C to 48.5°C)
Supply Temperature High	Supply Temperature High Limit
Limit Default value: 120°F (49°C)	Supply air high temperature value at which the heating stages get locked out.
AV99	Range: 70°F to 150°F (21°C to 65°C)
Supply Temperature Low	Supply Temperature Low Limit
Limit Default value: 45°F (7°C)	Supply air low temperature value at which the cooling stages get locked out.
AV20	Range: 35°F to 65°F (2.0°C to 19.0°C)

Parameter Default Value	Significance and Adjustments
Fan Control in Heating Mode Default value: On MV95	 Fan Control in Heating Mode Off: Fan (terminal G), when heating stages (terminals W1 & W2) are solicited, will not be energized. The fan is controlled by the equipment fan limit control. Valid only for Auto fan mode. On fan mode leaves the fan always on. On: Room Controller always controls the fan (terminal G). Valid for On or Auto fan mode. For multi-stage models, fan control applies to W1 & W2. Choices: 1=Off, 2=On
Fan Delay Default value: On MV12	 Fan Delay On: Fan mode will leave the fan always on and extends fan operation by 60 seconds after the call for heating or cooling ends. Valid only for Auto fan mode. Off: Fan delay not operational.
	Choices: 1=Off, 2=On
Proportional Band Default value: 3°F (2°C) AV65	 Proportional Band Adjusts proportional band used by Room Controller PI control loop. NOTE: Default value of 3 gives satisfactory operation in most normal installation cases. The use of a superior proportional band different than the factory value is normally warranted in applications where Room Controller location is problematic and leads to unwanted cycling of the unit. A typical example is a wall mounted Room Controller installed between return and supply air feeds and is directly influenced by the supply air stream of unit. Range: 3°F to 10°F (2°C to 5.5°C) – Resolution: 0.5°F/C
Power-up Delay Default value: 10 seconds AV76	 Power-up Delay On initial power up of the Room Controller there is a delay before any operation is authorized (fan, cooling or heating). This can be used to sequence the start up of multiple Room Controllers in one location. Range: 10 to 120 seconds (Resolution: 1 second)

Setpoint Configuration



Parameter Default Value	Significance and Adjustments
Setpoint Function	Setpoint Function
Default value: Attached	Local setpoint settings to set the local setpoint interface for the User.
Setpoints MV58	 Dual Setpoints: "Minimum" Deadband, Heat and Cool Setpoints can be adjusted independently. Attached Setpoints: Fixed Deadband in occupied mode, Heat and Cool setpoints always follow each other, separated by Deadband value (acts like a single setpoint).
	Choices: 1=Dual Setpoints, 2=Attached Setpoints
Deadband	Minimum Deadband
3.0°F (1.5°C) AV63	Temperature offset between the Cooling and Heating setpoints to ensure that Cooling setpoint is always warmer than the Heating setpoint.
	Cooling setpoint ≥ (Heating setpoint + Deadband)
	Range: 2.0°F to 5.0°F (1.0°C to 2.5°C)
Default Occupied	Default Setpoints
Default value: Disabled	Indicates whether the Room Controller follows Default Occupied Setpoints.
MV205	Choices: 1=Disabled, 2=Enabled
Standby Mode Default value: Absolute MV11	 Standby Mode Configuration Absolute: Standby setpoints are individually configurable Offset – Standby setpoints are automatically managed by the Room Controller with: Standby Cooling Setpoint = Occupied Cooling Setpoint + Standby Differential Standby Heating Setpoint = Occupied Heating Setpoint - Standby Differential
	Choices: 1=Absolute, 2=Offset
Cooling Setpoint Minimum Default value: 54.0°F (12.0°C) AV59	 Minimum Cooling Setpoint Limit Cooling Setpoint Minimum is applied to all setpoints, as it is the physical limit of how cold we want to allow the space to be chilled too. There is no reason an Unoccupied or Standby setpoint would want to be colder than the user allowed Cooling Setpoint Minimum. Cooling Setpoint Minimum cannot be more than the deadband above Heating Setpoint Maximum, otherwise it is not possible to respect the attached setpoints and deadband.
	Kange : 54.0°F to 100.0°F (12.0°C to 38.0°C)

Parameter Default Value	Significance and Adjustments
Heating Setpoint Maximum	Maximum Heating Setpoint Limit
Default value: 90.0°F (32.0°C) AV58	Heating Setpoint Maximum is applied to all setpoints, as it is the physical limits of how hot we want to allow the space to be heated too. There is no reason an Unoccupied or Standby setpoint would want to be hotter than the user allowed Heating Setpoint Maximum.
	Range: 40.0°F to 90.0°F (4.5°C to 32.0°C)

Lights and Blinds



Parameter Default Value	Significance and Adjustments
Blind Configuration	Refer to "Blind Configuration" on page 48 for more information.
Light Configuration	Refer to "Light Configuration" on page 50 for more information.

Blind Configuration



Parameter Default Value	Significance and Adjustments
Blind 1 to 8	Refer to "Blind 1 to 8" on page 49 for more information.



Parameter Default Value	Significance and Adjustments
Display Name Default value: Blind # CSV52 to CSV59	Blind # Display Name
	Enter the blind display name. The blind display name will be displayed for each blind element on the Blinds home screen, refer to "Blinds (Main)" on page 10 for more information.
	Note : The blind display name will be shortened to about 9 characters for each blind element on the Blinds home screen and to about 18 characters on the blind element popup.
	Range : 0 to 32 characters (a-z, A-Z, 0-9, @~+=^<>,.½:;*``, and spaces)
Enabled	Blind # Cfg
Default value: Disabled AV324 to AV331	Enable the blind configuration on the home screen.
	Choices: 0=Disabled, 1=Enabled

Light Configuration

< Light Configuration	۵
Light 1 Fochled Dimmable	>
Light 2 Enabled, Dimmable	>
Light 3 Enabled, Non dimmable	>
Light 4 Enabled, Dimmable	>
Light 5 Enabled, Non dimmable	>
Light 6 Disabled, Non dimmable	>
Light 7 Disabled, Non dimmable	>
Light 8 Disabled, Non dimmable	>

Parameter Default Value	Significance and Adjustments
Light 1 to 8	Refer to "Light 1 to 8" on page 51 for more information.

Light 1 to 8



Parameter Default Value	Significance and Adjustments
Display Name Default value: Light # CSV44 to CSV51	Light # Display Name
	Enter the light display name. The light display name will be displayed for each light element on the Lights home screen, refer to "Lights (Main)" on page 9 for more information.
	Note : The light display name will be shortened to about 18 characters for each light element on the Lights home screen and on the light element popup.
	Range: 0 to 32 characters (a-z, A-Z, 0-9, @~+=^<>,.½:;*``, and spaces)
Enabled	Light # Cfg
Dimmable Default value: Disabled AV316 to AV323	Enable the light and dimmable configuration on the home screen.
	Choices: 0=Disabled, Non dimmable; 1=Disabled, Dimmable; 3= Enabled, Non dimmable; 3=
	Enabled, Dimmable

Lua



Parameter Default Value	Significance and Adjustments
Script	Refer to "Script" on page 53 for more information.
Status	Refer to "Status" on page 54 for more information.
Variables	Refer to "Variables" on page 56 for more information.

Script



Parameter Default Value	Significance and Adjustments
Lua Script	Lua Script
Default value: No script loaded Read Only	If a Lua script has been loaded onto the Room Controller, this screen displays of the first lines, truncating scripts that are longer than ~22 lines with an ellipsis.
	If a script line exceeds the screen width, it will be wrapped, causing it to span two (or more) of the displayed lines.
	Tabs are displayed as 4 spaces, to ensure consistency of indented data.
	NOTE: This is just to allow the first lines to be viewed to help identify the loaded script.

Status



Parameter Default Value	Significance and Adjustments
Program Control Default value: Run	Program Control
	Allows the user to enable/disable the execution of the script.
	Run: Lua script activated and runs continuously until deactivated.Stop: Lua script deactivated.
	Choices: Run or Stop
Remote Device Access	Remote Device Access
Default value: Disabled Read Only (on BACnet) MV193	This feature is only editable by an Administrator user. It is used to indicate whether it is possible to access this Room Controller remotely.
	Choices: 1=Disabled, 2=Enabled
Program Status Default value: Disabled Read Only	Program Status
	 Running: Program is running normally. Halted: Program has been halted (via BACnet) or unloaded. Idle: Program is idle, not present or not yet running. Loading: Script is being loaded from disk.
	Display Readings: Disabled or Enabled
Program Error	Program Error
Default value: No error Read Only	Displays errors related to the execution of the Lua script, with values such as:
	 No error Syntax: Syntax error detected in the script. Runtime: Runtime error occurred when running the script. Memory: Device has run out of memory for the script.
	Display Readings: No error, Syntax, Runtime, Memory

Parameter Default Value	Significance and Adjustments
Debug Log Read Only	Debug Log
	Displays a debug log related to the execution of the Lua script, with the following information:
	 Messages printed from the Lua script. Error-related information, such as: Date and time of the error Line number (for syntax errors) Error message

Variables

There are also 18 "scratchpad" variables that are available from the Lua engine and BACnet or Modbus, but they are not visible from the Room Controller's HMI: AV338 to AV355, named "Lua Scratchpad 1" to "Lua Scratchpad 18". The scratchpad variables are editable via BACnet or Modbus only. Refer to the Lua4RC Programming Guide for more information.

		Lua	a V	ariables	
F	Darame	eter A	A (A	V25)	
	<	0	>	AV25	
F	Darame	eter E	3 (A	V26)	
	<	-1	>	AV26	
F	Darame	eter C	C (A	V27)	
	<	0	>	AV27	
F	Parame	eter D) (A	V28)	
	<	0	>	AV28	
F	Parame <	eter E -1	E (A' >	V29) AV29	
		Ok		Cancel	

Parameter Default Value	Significance and Adjustments
Parameter A (AV25)	Lua Parameter A (AV25)
Default value: 0 AV25	The value of this parameter depends on what is assigned to it from a BAS or Lua script.
Parameter B (AV26)	Lua Parameter B (AV26)
AV26	The value of this parameter depends on what is assigned to it from a BAS or Lua script.
Parameter C (AV27)	Lua Parameter C (AV27)
AV27	The value of this parameter depends on what is assigned to it from a BAS or Lua script.
Parameter D (AV28)	Lua Parameter D (AV28)
AV28	The value of this parameter depends on what is assigned to it from a BAS or Lua script.
Parameter E (AV29)	Lua Parameter E (AV29)
AV29	The value of this parameter depends on what is assigned to it from a BAS or Lua script.
Parameter F (AV30)	Lua Parameter F (AV30)
AV30	The value of this parameter depends on what is assigned to it from a BAS or Lua script.
Parameter G (AV31)	Lua Parameter G (AV31)
AV31	The value of this parameter depends on what is assigned to it from a BAS or Lua script.
Parameter H (AV32)	Lua Parameter H (AV32)
AV32	The value of this parameter depends on what is assigned to it from a BAS or Lua script.
Parameter I (AV33)	Lua Parameter I (AV33)
Default value: 0 AV33	The value of this parameter depends on what is assigned to it from a BAS or Lua script.

Parameter Default Value	Significance and Adjustments
Parameter J (AV34)	Lua Parameter J (AV34)
Default value: 0 AV34	The value of this parameter depends on what is assigned to it from a BAS or Lua script.
Parameter K (AV35)	Lua Parameter K (AV35)
AV35	The value of this parameter depends on what is assigned to it from a BAS or Lua script.
Parameter L (AV36)	Lua Parameter L (AV36)
AV36	The value of this parameter depends on what is assigned to it from a BAS or Lua script.
Parameter M (AV332)	Lua Parameter M (AV332)
Default value: 0 AV332	The value of this parameter depends on what is assigned to it from a BAS or Lua script.
Parameter N (AV333)	Lua Parameter N (AV333)
Default value: 0 AV333	The value of this parameter depends on what is assigned to it from a BAS or Lua script.
Parameter O (AV334)	Lua Parameter O (AV334)
Default value: 0 AV334	The value of this parameter depends on what is assigned to it from a BAS or Lua script.
Parameter P (AV335)	Lua Parameter P (AV335)
Default value: 0 AV335	The value of this parameter depends on what is assigned to it from a BAS or Lua script.
Parameter Q (AV336)	Lua Parameter Q (AV363)
Default value: 0 AV336	The value of this parameter depends on what is assigned to it from a BAS or Lua script.
Parameter R (AV337)	Lua Parameter R (AV337)
Default value: 0 AV337	The value of this parameter depends on what is assigned to it from a BAS or Lua script.

My Profile



Parameter Default Value	Significance and Adjustments			
User ID	Active User Id			
Read Only CSV31	Displays the user name of this profile, unique on this device.			
	Display Readings : 3 to 32 characters (a-z, A-Z, 0-9, @~+=^<>,.½:;,*'`, and spaces)			
Display Name	Display Name			
	Displays the official name of the profile, shown on the screens throughout the device.			
	Display Readings: 3 to 32 characters (a-z, A-Z, 0-9, @~+=^<>,.½:;*'`, and spaces)			
Role Read Only	Role			
	Displays the user role attached to this profile:			
	 Administrator: Full access Technician: Access to HVAC and local Room Controller-related configuration, but not to IP, FWU, etc. 			
	Display Readings: Administrator or Technician			
Change PIN	Refer to "Change PIN" on page 59 for more information.			

Change PIN

<	Change PIN	Ĉ
User I User N	D Jame	
Old P	IN	0
New I	PIN	0
Confi	rm New PIN	

Parameter Default Value	Significance and Adjustments
User ID	Active User Id
Read Only CSV31	Displays the user name of this profile, unique on this device.
	Display Readings : 3 to 32 characters (a-z, A-Z, 0-9, @~+=^<>,.½:;*'`, and spaces)
Old PIN	Old PIN
	Enter the current PIN for this profile.
	Range: 0 to 9999
New PIN	New PIN
	Enter the new PIN for this profile.
	Range: 0 to 9999
Confirm New PIN	Confirm New PIN
	Enter the new PIN once again for this profile.
	Range: 0 to 9999

Network

The user can select the protocol:



Parameter Default Value	Significance and Adjustments
BACnet	Refer to "BACnet" on page 61 for more information.
Modbus	Refer to "Modbus" on page 63 for more information.
WiFi	Enable WIFI
Default value: Disabled	Used to disable/enable the Wi-Fi network.
	Choices: Disabled, Enabled
WiFi Network	WiFi Network
	If the WiFi toggle switch is set to Disabled, this field will be uneditable and will indicate: Disabled: WiFi not enabled
	Otherwise, tapping this option will open the screen where a Wi-Fi network can be added or selected.
	Refer to "WiFi Network" on page 64 for more information.
Zigbee Network	Zigbee Network Status
Read Only MSI2	Displays the current status of the Zigbee network. Tap to display Zigbee Network screen where more features can be configured. Refer to "Zigbee Network" on page 69 for more information.
	Display Readings : Disabled, Initializing, Upgrading, Searching, Joining, Forming, Resuming, Online, Failed
Zigbee Devices	Paired Zibgee Devices
Read Only AI330	Displays the number of Zigbee devices paired with the Room Controller. Tap to display Zigbee Devices screen where 20 devices can be configured. Refer to "Zigbee Devices" on page 71 for more information.
	Display Readings: 0 to 20

BACnet

BACnet network screen shows when BACnet MS/TP is selected in wired protocol parameter.

BACnet	
Network Type MSTP	\checkmark
Status Offline	
Instance Number	
93001	
Network Units Imperial	~
COM Address	
< 254 >	
Baud Rate Auto	~

Parameter Default Value	Significance and Adjustments
Network Type Default value: Disabled	 Network Type MSTP: Only available if the Modbus Network Type is set to RTU. IP: Only available if IP is present on the device. Choices: 1=Disabled, 2=MSTP, 3=IP
Status Read Only MSI318	 BACnet Server Status Read Only value shows if a BACnet Network is detected or not. MSTP – Online when: BACnet/MSTP is enabled RS-485 communicated is detected online IP – Online when: BACnet/MSTP is enabled Wi-Fi network is online IP address is valid
Instance Number Default value: Last 4 digits of serial number	Instance Number Configurable number that identifies a device uniquely on the entire interconnected BACnet network. Range: 0 to 4194302 (22-bit)
Network Units Default value: Imperial MV6	 Network Units Network units transmitted over the BACnet network. NOTE: Use the Temperature scale parameter to change the display units locally on the Room Controller. SI: Network units shown as International Metric units. Imperial: Network units shown as Imperial units. Choices: 1=SI, 2=Imperial

Parameter Default Value	Significance and Adjustments
COM Address	COM Address
Default value: 254 AV10	Room Controller networking address.
	Default value of 254 disables BACnet communication for the Room Controller.
	Note: This field only appears when the MSTP Network Type is selected.
	Range: 0 to 254
Baud Rate	BACnet Baud Rate
Default value: Auto MV8	Leave the value at Auto unless instructed otherwise as this automatically detects BACnet baud rate.
	Note: This field only appears when the MSTP Network Type is selected.
	Choices : 1=9600, 2=19200, 3=38400, 4=57600, 5=76800, 6=115200, 7=Auto
Port	Port
Default value: 4/808	Port number for the IP Network.
	Note: This field only appears when the IP Network Type is selected.
	Range: 1024 to 65534
Foreign Device Registration	Foreign Device Registration
Default value: Disabled	A "foreign" device in the context of BACnet refers to a device that operates on a different IP subnet than the BACnet/IP network it is trying to communicate with. These devices require a process known as "foreign device registration" to join the BACnet network, allowing them to communicate with other BACnet devices despite being on a different subnet.
	Note: This field only appears when the IP Network Type is selected.
	Choices: Disabled, Enabled
BBMD Status	BBMD Status
Read Only MV207	A BBMD (BACnet Broadcast Management Device) is essential for handling broadcasts across different IP subnets. The BBMD helps ensure that broadcast messages can be communicated effectively between devices on different subnets.
	Display Readings: Offline, DNS Lookup, DNS Fail, Registering, Registered, Registration Failed
BBMD Address	BBMD Address
	BACnet Broadcast Management Device address.
BBMD Port	BBMD Port
	BACnet Broadcast Management Device port number.
	Range: 1024 to 65534
BBMD TTL (seconds)	BBMD TTL (seconds)
Default value: 300	Time to Live delay in seconds.
	Range: 0 to 65535

Modbus

Modbus network screen shows when Modbus is selected in wired protocol parameter.



Parameter Default Value	Significance and Adjustments
Network Type	Network Type
Default value: Disabled	RTU: Only available if the BACnet Network Type is not set to MSTP.
	Choices: Disabled or RTU
COM Address	COM Address
Default value: 254	Room Controller networking address.
	NOTE: A COM Address may be shared between Modbus and BACnet/MSTP.
	Range: 0 to 254
Network Units	Network Units
Default value: Imperial	Network units transmitted over the Modbus network.
	NOTE: Use the Temperature scale parameter to change the display units locally on the Room Controller.
	SI: Network units shown as International Metric units.Imperial: Network units shown as Imperial units.
	Choices: 0=SI, 1=Imperial
Baud Rate	Modbus Baud Rate
Default value: 19200	Select the applicable Modbus baud rate.
	Choices : 0=4800, 1=9600, 2=19200, 3=38400, 4=57600
Parity	Modbus Parity Bit
Default value: Even	Determines how the parity bit of the character's data frame is set to detect any errors in the sent/receives frame.
	Choices: 0=None, 1=Odd, 2=Even

WiFi Network



Parameter Default Value	Significance and Adjustments
Add Hidden Network	Tap to open the screen and add a hidden Wi-Fi network.
	Refer to "Hidden Network" on page 65 for more information.
Search for Network	Tap and enter a Service Set Identifier (SSID), tap Update Search Results, then tap on the de- sired network name. Refer to "Connect to a Wi-Fi Network" on page 67 for more information.

Hidden Network



Parameter Default Value	Significance and Adjustments
Network Name	WiFi Network SSID
CSV7	Service Set Identifier (SSID), the Wi-Fi network name.
	Range : 1 to 32 characters (a-z, A-Z, 0-9, @~+=^<>,.½:;**``, and spaces)
Security	WiFi Security Type
Default value: UNKNOWN SECURITY	Security protocol used for this Wi-Fi network.
MV206	Choices: 1=WPA2 AES PSK, 2=WPA2 TKIP PSK, 3=WPA2 MIXED PSK, 4=WPA3 SAE, 5=WPA3 WPA2 PSK, 6=UNKNOWN SECURITY
Password	Password
	Unique password linked to this Wi-Fi network.
	Range : 8 to 63 characters (a-z, A-Z, 0-9, @~+=^<>,.1/2:;*'`, and spaces)
Show Advanced Settings	Show Advanced Settings
Default value: Disabled	Used to display more settings related to the configuration of this Wi-Fi network.
	Choices: Disabled, Enabled
IP Settings	Enable Static IP
Default value: Dynamic MV183	 Dynamic (DHCP): If this option is selected, a field requiring the Domain Name System (DNS) server is displayed. Static: If this option is selected, refer to the following rows for the required information.
	Choices: 1=Dynamic (DHCP), 2=Static
IP Address	IP Address
Default value: Empty	Internet Protocol (IP) address that is assigned to the device.
	Range: 0 to 255 characters

Parameter Default Value	Significance and Adjustments
Mask	Mask
Default value: Empty	Mask address that is assigned to the device.
	Range: 0 to 255 characters
Gateway	Gateway
Default value: Empty	Gateway address that is assigned to the device.
	Range: 0 to 255 characters
DNS	DNS
Default value: Empty	Domain Name System (DNS) address that is assigned to the device.
	Range: 0 to 255 characters

Connect to a Wi-Fi Network

The name appearing at the top of the screen will be the name of the network that was selected. Refer to "WiFi Network" on page 64.

<	Network Name	
Pass	sword	
Ent	er password	0
Sho	w Advanced Settings	
IP S Stati	ettings ic	~
IP A	ddress	
192	2.168.2.3	
Mas	k	
192	2.168.2.3	
Gate	eway	
192	2.168.2.3	

Parameter Default Value	Significance and Adjustments
Password	Password
	Unique password linked to this Wi-Fi network.
	Range: 8 to 63 characters (a-z, A-Z, 0-9, @~+=^<>,.½:;*``, and spaces)
Show Advanced Settings	Show Advanced Settings
Default value: Disabled	Used to display more settings related to the configuration of this Wi-Fi network.
	Choices: Disabled, Enabled
IP Settings	Enable Static IP
Default value: Dynamic MV183	 Dynamic (DHCP): If this option is selected, a field requiring the Domain Name System (DNS) server is displayed. Static: If this option is selected, refer to the following rows for the required information.
	Choices: 1=Dvnamic (DHCP), 2=Static
IP Address	IP Address
Default value: Empty	Internet Protocol (IP) address that is assigned to the device.
	Range: 0 to 255 characters
Mask	Mask
Default value: Empty	Mask address that is assigned to the device.
	Range: 0 to 255 characters
Gateway	Gateway
Default value: Empty	Gateway address that is assigned to the device.
	Range: 0 to 255 characters

Parameter Default Value	Significance and Adjustments
DNS	DNS
Default value: Empty	Domain Name System (DNS) address that is assigned to the device.
	Range: 0 to 255 characters

Zigbee Network



Parameter Default Value	Significance and Adjustments
Node Type	Node Type
Default value: Disabled	A Zigbee network is made up of entities called nodes:
	 Disabled: No Zigbee network. Coordinator: Zigbee Coordinator (ZC) is responsible for forming the network. A coordinator can be seen as a router with additional functionality. There can be only one coordinator in a
	single network.
	Choices: Disabled or Coordinator
Network Status	Zigbee Network Status
Default value: Disabled Read Only MSI2	Current status of the Zigbee network.
	Display Readings : Disabled, Initializing, Upgrading, Searching, Joining, Forming, Resuming, Online, Failed
PAN ID	PAN ID
Default value: 1	Zigbee networks are called personal area networks (PANs). Each network is defined with a unique PAN identifier (PAN ID).
	Range: 1 to 65535
Channel	Channel
Default value: 11	A Zigbee channel is a narrow band of radio frequency used by Zigbee devices to communicate wirelessly.
	Range: 11 to 26
Security Read Only	Security
	Display Readings: Normal

Parameter Default Value	Significance and Adjustments
Permit Join	Permit Join
Default value: Disabled	Enables the coordinator to send the link key (required to join the network) to devices.
	Choices: Disabled, Enabled
Network Address	Network Address
Read Only	A 16-bit address that a device receives when it joins a Zigbee network
IEEE Address	ZigBee IEEE Address
Read Only CSV10	A unique 64-bit identifier assigned to each ZigBee device by the manufacturer.
	Range: 0 to 18 characters

Zigbee Devices



Parameter Default Value	Significance and Adjustments
Device #: Name	Device #: Name
Ready Only	Tapping on a device will display its information and offer the possibility of removing the device.

Occupancy



Parameter Default Value	Significance and Adjustments
Occupancy Configuration	Refer to "Occupancy Configuration" on page 73 for more information.
Occupancy Schedule	Refer to "Occupancy Schedule" on page 75 for more information.
Occupancy Configuration



Parameter Default Value	Significance and Adjustments		
Standby Time Default value: 0.5 Hours AV67	Standby Time		
	Time between the moment where the PIR cover detects last movement in the area, and the time which the Room Controller stand-by setpoints become active.		
	NOTE: This parameter is not active when the Door function is used (wired or wireless).		
	Range: 0.5 to 24 Hours (Resolution: 0.5 Hours)		
Unoccupied Time	Unoccupied Time		
Default value: 0.0 Hours AV68	Time between the moment where the Room Controller toggles to stand-by mode, and the time which the Room Controller unoccupied mode and setpoints become active.		
	NOTE: Default value of 0.0 hours disables the unoccupied timer. This prevents the Room Controller from being able to switch from stand-by mode to unoccupied mode when PIR functions are used.		
	Range: 0.5 to 24 Hours (Resolution: 0.5 Hours)		
Temporary Occupancy	Temporary Occupancy Time		
Default value: 2 Hours AV62	The time the Room Controller stays in override mode before reverting back to unoccupied mode. When the Room Controller is in unoccupied mode, pressing the on-screen Override icon or closing the contact on UI17, configured as Remote Override, sets the Room Controller to Override mode for defined time period, and uses the Occupied Cooling and Heating setpoints.		
	Range: 0 to 24 Hours (Resolution: 1 Hour)		
Occupancy Command Default value: Occupied MV10	Occupancy Command		
	Allows quick workaround of faults in motion sensors, etc.		
	 Local Occupancy: Occupancy is determined by local sequences (either PIR or schedule or a combination of both, as configured under Occupancy Source). Occupied: Forces occupied mode. Unoccupied: Forces unoccupied mode. 		
	Choices: 1=Local Occupancy, 2=Occupied, 3=Unoccupied		

Parameter Default Value	Significance and Adjustments		
Occupancy Source	Occupancy Source		
Default value: Motion MV110	 Motion: Occupancy status is received from a motion sensor. Schedule: Occupancy status is determined by the schedule. Motion during Schedule: Occupied when scheduled occupied AND when motion is detected. Motion or Schedule: Occupied when scheduled occupied OR when motion is detected. 		
Conversion of Conversion	Choices: 1=Motion, 2=Schedule, 3=Motion during Schedule, 4=Motion or Schedule		
Default value: High	Occupancy Sensor		
MV188	The Room Controller uses a PIR for Occupancy sensing that can be configured with sensitivities. When enabled, this feature sets the Local Motion point to active upon detection of occupancy.		
	The target ranges for occupancy modes are:		
	 Off: No sensibilities Low: 1 meter (3.28 feet) Medium: 4 meter (13.12 feet) High: 8 meter (26.25 feet) 		
	Choices: 1=Off, 2=Low, 3=Medium, 4=High		
Smart Recovery	Smart Recovery Status		
Default value: Off Read Only BV40	 Off: No smart recovery. The occupied schedule time is the time at which the system will restart. On: Smart recovery active. The occupied schedule time is the time at which the desired occupied temperature will be attained. The Room Controller automatically optimizes the equipment start time. In any case, the latest a system will restart is 10 minutes prior to the occupied period time. 		
	Smart recovery is automatically disabled if U1 is configured to remote NSB.		
	Display Readings: Off, On		
Binary Aux. Output	Auxiliary Output		
Configuration Default value: Normally Open	Normally Open:Normally Closed:		
Read Only MV92	Display Readings: Normally Open, Normally Closed		

Occupancy Schedule

There are seven different schedule setting screens, one for each day of the week. Each day can have different scheduled events where the Room Controller is set to Occupied status or back to Unoccupied status. The Room Controller can use the appropriate setpoints (back and forth) up to three times per day.



Parameter Default Value	Significance and Adjustments		
Schedule Type Default value: 7 days MV136	Schedule Type		
	 7 days: Independent scheduling identified by day of the week (Sunday - Saturday). 5+1+1 days: Weekdays scheduling and Independent Weekend scheduling identified as Weekdays, Saturday and Sunday. 5+2 days: Weekdays scheduling and Weekend scheduling identified as Weekdays and Weekend. 		
	Choices : 1=7 days, 2=5+1+1, 3=5+2		
Occupied 1 – 3	Occupied 1 – 3		
Default value: None	Defines a time when the Room Controller is automatically set to use the Occupied setpoint.		
	: indicates no time is set for the Occupied setpoint.		
	NOTE: There are 3 separate Occupied parameter entries.		
	Range: 00:00 - 23:59, or:		
Unoccupied 1 – 3	Unoccupied 1 – 3		
Default value: None	Defines a time when the Room Controller is automatically set to use the Unoccupied setpoint.		
	: indicates no time is set for the Unoccupied setpoint.		
	NOTE: There are 3 separate Unoccupied parameter entries.		
	Range: 00:00 - 23:59, or:		

Preferences

This Preferences screen is available via the Setup.



Parameter Default Value	Significance and Adjustments		
Country	Country		
	Offers the possibility of conditionally configuring the country of operation based on the factory- locked country code of the Room Controller.		
	If the manufacturing region of the Room Controller is:		
	Defined: This field will use the same value and will not be editable.Not defined: This field will be a drop-down list of available countries to choose from.		
	Note: This feature is not available on the North American Room Controller model.		
Date and Time	Date and Time		
	Defines the current date and time: Year-Month-Day + 12 hour AM-PM or 24 hour format.		
	The latter is determined by the Time Format parameter value. Refer to "Display" on page 78 for more information.		
Display	Refer to "Display" on page 78 for more information.		
Halo	Refer to "Halo" on page 80 for more information.		
Language Selection	Refer to "Language Selection" on page 81 for more information.		
Time Zone	Refer to "Time Zone" on page 83 for more information.		

Date and Time



Parameter Default Value	Significance and Adjustments		
Date	Date		
Default value: Current date at power up	Standard date display, Year/Month/Day.		
Time Default value: Current time at power up	Time Standard time display, 12 hour AM-PM or 24 hour format determined by the Time Format parameter value. Refer to "Display" on page 78 for more information.		

Display



Parameter Default Value	Significance and Adjustments				
Backlight Minimum	Night Backlight				
Brightness	Sets the lowest display backlight intensity.				
AV4	Range: 0% to Value of Backlight Inactive Maximum Brightness (e.g. 60%) (Resolution: 1%)				
Backlight Inactive	Low Backlight				
Maximum Brightness	Sets the display backlight intensity. This feature is activated (screen dims) after 150 seconds of				
Default value: 60%	no activity on the Room Controller.				
AV3	Range: Value of Backlight Minimum Brightness (e.g., 5%) to 100% (Resolution: 1%)				
Button 1	Button 1				
Default value: System Mode					
MV195	Used to configure the feature controlled by the first of three buttons on the home screen.				
	Choices: 1=Disabled, 2=System Mode, 3=Fan Mode, 4=AI Eco Mode				
Button 2	Button 2				
Default value: Fan Mode	Used to configure the feature controlled by the second of three buttons on the home screen.				
	Choices: 1=Disabled, 2=System Mode, 3=Fan Mode, 4=AI Eco Mode				
Button 3	Button 3				
Default value: Al Eco Mode	Used to configure the feature controlled by the third of three buttons on the home screen.				
	Choices: 1=Disabled, 2=System Mode, 3=Fan Mode, 4=AI Eco Mode				
Inactivity Time	Inactivity Time				
Default value: 3 Minutes	Used for:				
AV231	Standby screen activation				
	Backlight inactivity timeout				
	Range: 1 to 10 Minutes (Resolution: 1 Minute)				

Parameter Default Value	Significance and Adjustments		
Info Item 1	Info Item 1		
Default value: Humidity MV200	Used to configure the information shown on the first of three lines on the home screen. Each information can only be shown on one Info Item. If one is selected on a second Info Item, the first item will be set to Disabled.		
	Choices : 1=Disabled, 2=Humidity, 3=CO ₂ Level, 4=Outdoor Air Temperature		
Info Item 2	Info Item 2		
Default value: CO ₂ Level MV201	Used to configure the information shown on the second of three lines on the home screen. Each information can only be shown on one Info Item. If one is selected on a second Info Item, the first item will be set to Disabled.		
	Choices : 1=Disabled, 2=Outdoor Air Temperature, 3=Humidity, 4=CO ₂ Level		
Info Item 3	Info Item 3		
Default value: Outdoor Air Temperature MV202	Used to configure the information shown on the third of three lines on the main display. Each information can only be shown on one Info Item. If one is selected on a second Info Item, the first item will be set to Disabled.		
	Choices : 1=Disabled, 2=Outdoor Air Temperature, 3=Humidity, 4=CO ₂ Level		
Notifications	Notification Display Type		
Default value: All	Used to configure the display of notifications on screen:		
MV187	 Disabled: No notifications shown. Custom Only: Custom notifications shown, but no In-built notifications. All: Custom and in built notifications shown. 		
	Choices: 1=Disabled, 2=Custom Only, 3=All		
Setpoint Control	HMI Setpoint		
Default value: Slider	Used to configure the temperature setpoint control type on the home screen.		
1010 192	Choices: 1=None, 2=Slider, 3=Buttons (Attached SP Only)		
Standby Screen	Use Standby Screen		
Default value: Disable MV32	Used to choose whether to display a custom image or not when the Room Controller switches to Standby Mode after a configurable amount of inactive time.		
	Choices: 1=Disabled, 2=Custom Image		
Time Format	Time Format		
Default value: 12 Hour (AM-	Used to configure the user's preferred display time format.		
MV5	For example:		
	 12 Hour (AM-PM): 5:41 PM 24 Hour: 17:41 or 01:23 		
	Choices: 1=12 Hour (AM-PM), 2=24 Hour		

Halo



Parameter Default Value	Significance and Adjustments	
Halo Mode Default value: Heat/Cool MV194	 Halo Mode Disabled: Halo remains off Heat/Cool: Orange: Heating Blue: Cooling Off: On standby (room temperature at setpoint) 	
	Choices: 1=Disabled, 2=Heat/Cool	
Halo Maximum Brightness Default value: 100% AV236	Halo Maximum Brightness Controls the maximum brightness of the halo LED. Range: 0% to 100%	

Language Selection

Only English, French, Spanish, Chinese, and Russian are enabled by default and are accessible to users cycling through languages on the main Preferences screen. To change the language selection settings, tap a language on the screen and then use the arrow buttons to disable or enable it.

NOTE: English is always enabled.



Parameter Default Value	Significance and Adjustments
Arabic	Arabic
MV120	Choices: 1=Disabled, 2=Enabled
Chinese	Chinese
MV103	Choices: 1=Disabled, 2=Enabled
Czech	Czech
MV122	Choices: 1=Disabled, 2=Enabled
Danish	Danish
Default value: Disabled MV123	Choices: 1=Disabled, 2=Enabled
Dutch	Dutch
Default value: Disabled MV124	Choices: 1=Disabled, 2=Enabled
Finnish	Finnish
Default value: Disabled MV125	Choices:1=Disabled, 2=Enabled
French Default value: Enabled MV101	French
	Choices: 1=Disabled, 2=Enabled
German Default value: Disabled MV126	German
	Choices: 1=Disabled, 2=Enabled
Hebrew	Hebrew
Default value: Disabled MV160	Choices: 1=Disabled, 2=Enabled

Parameter Default Value	Significance and Adjustments
Hungarian	Hungarian
Default value: Disabled MV127	Choices: 1=Disabled, 2=Enabled
Indonesian	Indonesian
MV128	Choices: 1=Disabled, 2=Enabled
Italian Defaulture Disabled	Italian
MV129	Choices: 1=Disabled, 2=Enabled
Japanese Defaulture Disabled	Japanese
MV159	Choices: 1=Disabled, 2=Enabled
Norwegian	Norwegian
MV130	Choices: 1=Disabled, 2=Enabled
Polish	Polish
MV131	Choices: 1=Disabled, 2=Enabled
Portuguese	Portuguese
MV132	Choices: 1=Disabled, 2=Enabled
Russian	Russian
Default value: Enabled MV104	Choices:1=Disabled, 2=Enabled
Slovak	Slovak
MV133	Choices: 1=Disabled, 2=Enabled
Spanish Default values Frachlad	Spanish
MV102	Choices: 1=Disabled, 2=Enabled
Swedish Default value: Disabled MV134	Swedish
	Choices: 1=Disabled, 2=Enabled
Turkish	Turkish
MV135	Choices: 1=Disabled, 2=Enabled



Parameter Default Value	Significance and Adjustments		
Region Default value: Etc	Region Allows the user to configure their loc Choices: 1=Africa, 2=America, 3=A	cal time zone via the local interfa sia, 4=Australia, 5=Etc, 6=Europ	ce. pe, 7=Pacific
Time Zone Default value: UTC CSV40	 Timezone Africa Brazzaville (UTC 1:00) Cairo (UTC 2:00) Harare (UTC 2:00) Nairobi (UTC 3:00) America Anchorage (UTC -8:00) Buenos Aires (UTC -3:00) Chicago (UTC -5:00) Denver (UTC -6:00) Godthab (UTC -3:00) Halifax (UTC -3:00) Halifax (UTC -3:00) Los Angeles (UTC -7:00) Manaus (UTC -4:00) Mexico City (UTC -6:00) New York (UTC -6:00) Regina (UTC -7:00) Regina (UTC -6:00) Santiago (UTC -4:00) Sao Paulo (UTC -3:00) St Johns (UTC -1:30) Tijuana (UTC -7:00) 	Asia Bangkok (UTC 7:00) Chongqing (UTC 8:00) Dubai (UTC 4:00) Hong Kong (UTC 8:00) Jerusalem (UTC 2:00) Katmandu (UTC 5:45) Kolkata (UTC 5:30) Kuala Lumpur (UTC 8:00) Kuwait (UTC 3:00) Rangoon (UTC 6:30) Seoul (UTC 9:00) Shanghai (UTC 8:00) Taipei (UTC 8:00) Taipei (UTC 8:00) Tokyo (UTC 9:00) Australia Adelaide (UTC 10:30) Brisbane (UTC 10:00) Darwin (UTC 9:30) Hobart (UTC 11:00) Sydney (UTC 11:00) Eelected Region	 Etc. UTC Europe Amsterdam (UTC 1:00) Belgrade (UTC 1:00) Berlin (UTC 1:00) Brussels (UTC 1:00) Helsinki (UTC 2:00) Istanbul (UTC 3:00) London (UTC 0:00) Moscow (UTC 3:00) Rome (UTC 1:00) Sarajevo (UTC 1:00) Sarajevo (UTC 12:00) Guam (UTC 10:00) Honolulu (UTC -10:00) Majuro (UTC 12:00) Midway (UTC -11:00)

Service View



Parameter Default Value	Significance and Adjustments	
Alarms	Refer to "Alarms" on page 85 for more information.	
Environment	Refer to "Environment" on page 88 for more information.	
Operating Status	Refer to "Operating status" on page 90 for more information.	
System Status	Refer to "System Status" on page 91 for more information.	

Alarms

The information displayed on this screen depends on the Room Controller configuration and the installed sensors. When an alarm is active, a notification will be displayed in a banner on the top of the home screen. Refer to "Appendix D: Notifications" on page 110 for more information.



Parameter Default Value	Significance and Adjustments
Clock Alarm	Clock Alarm
Default value: Off	The Room Controller activates a Clock Alarm upon startup when:
Read Only BV8	 Occupancy Command is set to Local Occupancy. Occupancy Source is set to a value involving schedules. The Room Controller time is invalid, resulting in scheduled occupancy not functioning.
	Upon startup when Clock Alarm is active, the occupancy status will be Unoccupied.
	Notification type: Warning: Yellow banner
	Display Readings: 0=Off, 1=On
CO ₂ Alarm	CO ₂ Alarm
Default value: Off Read Only	The Room Controller activates a CO_2 Alarm when: The CO_2 level is greater than the configured "Maximum CO_2 " for 30 minutes or more.
	Notification type: Warning: Yellow banner
	Display Readings: 0=Off, 1=On
Fan lock Alarm	Fan Lock Alarm
Default value: Off Read Only BV39	The Room Controller supports Fan Lock Alarms: When the (G) Fan Output is activated, if this input is not activated after 10 seconds, the Room Controller disables Heat and Cool outputs and enables the "Fan Lock" alarm.
	The alarm is cleared when:
	Fan Lock input is activated, or (C) Fan is deastivated
	Notification type: Critical: Red banner
	Display Readings: 0=Off, 1=On

Parameter Default Value	Significance and Adjustments
Filter Alarm	Filter Alarm
Default value: Off	The Room Controller supports Filter Alarms.
Read Only	Active when:
BV36	Configurable input U2 is configured as Filter Alarm, AND
	Input is active
	 Inactive when: Configurable input U2 is not configured as Filter Alarm OR
	 Input is inactive
	Notification type: Critical: Red banner
	Display Readings: 0=Off, 1=On
Frost Alarm	Frost Protection Alarm
Default value: Off	The Room Controller supports Frost Alarms:
Read Only	The room frost protection operates in all system modes, even 'Off'.
BV43	When room temperature is less than 42°F (5.6°C):
	 Frost Protection alarm is activated. Pressure-Independent Heating Demand is forced to 100%
	Notification type: Critical: Red banner
	Display Readings: 0=Off, 1=On
Wireless Sensor Low	Low Battery Alarm
Default value: Off	The Room Controller supports Low Battery Alarms.
Read Only	Active when: Any paired Zigbee device has a low battery level.
BV5	Inactive when: All paired Zigbee devices have a normal battery level.
	Notification type: Warning: Yellow banner
	Display Readings: 0=Off, 1=On
Low Fresh Air Alarm	Low Fresh Air Alarm
Default value: Off	The Room Controller supports Low Fresh Air Alarms.
BV42	Enabled when: The "Fresh Air Range Upper Limit" is greater than zero.
	Active when: The tresh air flow is 15% or more below the configured "Minimum Fresh Air" for 30 minutes or more.
	Notification type: Warning: Yellow banner
O amaia a Alama	Display Readings: 0=0tt, 1=0n
Service Alarm Default value: Off Read Only	
	The Room Controller supports Service Alarms.
BV37	 Active when: Configurable input U2 is configured as Service Alarm AND
	Input is active
	Inactive when: Operation of the sector of the sec
	 Conligurable input 02 is not conligured as Service Alarm, OR Input is inactive
	Notification type: Critical: Red banner
	Display Pandings: 0-Off 1-On
Water Leak Alarm	Water Leak Alarm
Default value: Off	The Room Controller activates a Water Leak Alarm when:
Read Only	Active when any connected water leak sensor reports a look
BV44	 Inactive when all connected water leak sensors report no leak.
	Notification type: Critical: Red banner
	Display Readings: 0=Off, 1=On

Parameter Default Value	Significance and Adjustments
Window Alarm	Window Alarm
Default value: Off	The Room Controller supports Window Alarms.
BV35	 Active when: Any connected wired or wireless window sensor reports an open window. Inactive when: All connected wired and wireless window sensors report closed windows.
	Notification type: Warning: Yellow banner
	Display Readings: 0=Off, 1=On
Wireless Sensor Offline	Wireless Sensor Communication Alarm
Default value: Off Read Only	The Room Controller supports Wireless Sensor Communication Alarms.
BV50	Active when: Any paired Zigbee device stops comminicating.Inactive when: All paired Zigbee devices are communicating normally.
	Notification type: Warning: Yellow banner
	Display Readings: 0=Off, 1=On

Environment



Parameter Default Value	Significance and Adjustments
Room Temperature	Room Temperature
Read Only AV100	Displays the current room temperature.
	Display Readings: -40°F to 122°F (-40.0°C to 50.0°C)
Effective Temperature	Effective Temperature Sensor
Default value: Wired Read Only MSI309	Sets the source of the indoor room temperature. This parameter allows the user to designate either the Room Controller or any of the paired wireless devices that support temperature to function as the source for the room temperature.
	 Wired: Sets the thermistor connected to U4 (RS) as the source to report room temperature. Internal: Sets the Room Controller as the source for the room temperature. Wireless Sensor 1 to 20: Sets the selected Zigbee wireless device as the source for the room temperature. Only one device can be selected.
	NOTE: The Room Controller uses the internal temperature sensor only if the U4 (RS) terminal is empty. If a valid temperature sensor is connected to the U4 terminal, the Room Controller will use the sensor as the control point. Disconnecting the sensor, or if the sensor is faulty, the Room Controller will automatically revert to its internal temperature sensor.
	Display Readings : Wired, Internal, Wireless Sensor 1, Wireless Sensor 2, Wireless Sensor 3, Wireless Sensor 4, Wireless Sensor 5, Wireless Sensor 6, Wireless Sensor 7, Wireless Sensor 8, Wireless Sensor 9, Wireless Sensor 10, Wireless Sensor 11, Wireless Sensor 12, Wireless Sensor 13, Wireless Sensor 14, Wireless Sensor 15, Wireless Sensor 16, Wireless Sensor 17, Wireless Sensor 18, Wireless Sensor 19, Wireless Sensor 20
Wired Temperature Sensor	Wired Temperature Sensor
Default value: -40.0°F (-40.0°C) Read Only	Displays the current room temperature, as recorded by the Wired Temperature Sensor. All wired temperature sensors are 10,000 ohm Type 2 NTC thermistor.
AV105	Display Readings : -40.0°F to 180.0°F (-40.0°C to 82.0°C)
Outdoor Temperature	Outdoor Temperature
-40.0°F (-40.0°C) Read Only	Displays the outdoor temperature on the main screen. All wired temperature sensors are 10,000 ohm Type 2 NTC thermistor.
AV101	Display Readings : -40.0°F to 180.0°F (-40.0°C to 82.0°C)

Parameter Default Value	Significance and Adjustments
Supply Temperature	Supply Temperature
Default value:	Displays the supply air temperature, as measured by the sensor. All wired temperature sensors
-40.0°F (-40.0°C) Read Only	are 10,000 ohm Type 2 NTC thermistor.
AV102	
	Display Readings: -40.0°F to 180.0°F (-40.0°C to 82.0°C)
Humidity Read Only	Room Humidity
AV103	Indicates the current level of humidity inside this room.
	Display Readings: 0% to 100%
Effective Humidity Source	Effective Relative Humidity Sensor
Read Only	Indicates the type of relative humidity sensor used with this Room Controller.
	Display Readings: Wired, Internal, Wireless Sensor 1, Wireless Sensor 2, Wireless Sensor 3,
	Wireless Sensor 4, Wireless Sensor 5, Wireless Sensor 6, Wireless Sensor 7, Wireless Sensor 8,
	Sensor 13 Wireless Sensor 14 Wireless Sensor 15 Wireless Sensor 16 Wireless Sensor 17
	Wireless Sensor 18, Wireless Sensor 19, Wireless Sensor 20
CO2	CO2 Level
Default value: 0 PPM	Indicates the current level of CO, in parts per million (RDM)
Read Only	indicates the current level of CO_2 in parts per minion (PPM).
AVIO	Display Readings: 0 PPM to 5000 PPM
Effective CO2 Source	CO2 Effective Source
Default value: None Read Only	Indicates the type of CO ₂ sensor used with this Room Controller.
MSI324	Display Readings: None Internal Error Wired Wireless Sensor 1 Wireless Sensor 2 Wireless
	Sensor 3, Wireless Sensor 4, Wireless Sensor 5, Wireless Sensor 6, Wireless Sensor 7, Wireless
	Sensor 8, Wireless Sensor 9, Wireless Sensor 10, Wireless Sensor 11, Wireless Sensor 12,
	Wireless Sensor 13, Wireless Sensor 14, Wireless Sensor 15, Wireless Sensor 16, Wireless Sensor 17, Wireless Sensor 18, Wireless Sensor 19, Wireless Sensor 20
Door Switch Used	Door Contact Installed
Default value: No	Used to indicate that a Zigbee or wired door sensor is in use
BV2	
	Display Readings: 0=No, 1=Yes
Window Switch Used	Window Contact Installed
Delault value: NO Read Only	Used to indicate that a Zigbee or wired window sensor is in use.
BV4	
	Display Readings: 0=No, 1=Yes

Operating status



Parameter Default Value	Significance and Adjustments
Effective Occupancy Default value: Occupied	Effective Occupancy
	Displays the occupancy mode currently in operation.
MSI33	Display Readings: 1=Occupied, 2=Unoccupied, 3=Override, 4=Standby
Local Motion	PIR Local Motion
Read Only	Indicates whether the Motion alarm is active or not.
BV32	Display Readings: 0=No motion, 1=Motion
Effective System Mode	Effective System Mode
Default value: Cool Read Only MSI314	Displays the current operating mode of the system. For example, when the system is in Auto mode, this parameter shows whether it is currently heating or cooling.
	Display Readings: 1=Cool, 2=Heat
Effective Setpoint	Effective Setpoint
Default value: 40°F (4.5°C)	Displays the value of the temperature setpoint currently in operation.
Read Only AI329	Display Readings : 40.0°F to 100.0°F (4.5°C to 38.0°C)
Effective Fan Speed	Fan Speed Status
Default value: Off Read Only MSI326	Displays the fan speed currently in operation.
	Display Readings: 1=Off, 2=Low, 3=Medium, 4=High
Door Switch Used Default value: No Read Only BV2	Door Contact Installed
	Used to indicate that a Zigbee or wired door sensor is in use.
	Display Readings: 0=No, 1=Yes
Window Switch Used	Window Contact Installed
Default value: No Read Only	Used to indicate that a Zigbee or wired window sensor is in use.
BV4	Display Readings: 0=No, 1=Yes

System Status



Parameter Default Value	Significance and Adjustments
PI Cool Demand Default value: 0% Read Only AO22	PI Cooling Demand Displays the percentage of demand for cooling in the zone, using a Proportional-Integral control loop.
	Display Readings: 0% to 100% (Resolution: 1%)
PI Heat Demand	PI Heating Demand
Default value: 0% Read Only AO21	Displays the percentage of demand for heating in the zone, using a Proportional-Integral control loop.
	Display Readings: 0% to 100% (Resolution: 1%)
Cooling Demand Limit	Cooling Demand Limit
Default value: 100% Read Only AV89	Displays the configurable maximum limits for cooling. It is configurable via the BACnet and Modbus interfaces.
	Display Readings: 0% to 100% (Resolution: 1%)
Heating Demand Limit Default value: 100% Read Only AV88	Heating Demand Limit Displays the configurable maximum limits for heating. It is configurable via the BACnet and Modbus interfaces.
	Display Readings: 0% to 100% (Resolution: 1%)
Economizer Demand Read Only AO23	Economizer Demand Display Readings: 0-100%
Dehumidification Status	Dehumidification Status
Default value: Off Read Only BV38	Indicates whether dehumidification is currently active or inactive. Used when Dehumidification is enabled.
	Display Readings: 0=Off, 1=On

Parameter Default Value	Significance and Adjustments
Airflow Level Default value: 0 CFM Read Only AV107	Airflow Level Displays the amount of air (in cubic feet/minute or liters/second) that flows through a particular device.
	Display Readings: 0 to 20,000 CFM (0 to 9440 l/s)
Smart Recovery Status Default value: Off Read Only BV40	 Smart Recovery Status Off: No smart recovery. The occupied schedule time is the time at which the system will restart. On: Smart recovery active. The occupied schedule time is the time at which the desired occupied temperature will be attained. The Room Controller automatically optimizes the equipment start time. In any case, the latest a system will restart is 10 minutes prior to the occupied period time. Smart recovery is automatically disabled if U1 is configured to remote NSB. Display Readings: Off, On

Setpoints



Parameter Default Value	Significance and Adjustments
Unoccupied Cooling	Unoccupied Cool Setpoint
Setpoint Default value:	Displays the Cooling Temperature setpoint used when in Unoccupied mode.
80.0°F (26.5°C)	Range : 54.0°F to 100.0°F (12.0°C to 37.5°C)
AV44	
Standby Cooling Setpoint	Standby Cool Setpoint
78.0°F (25.5°C)	Displays the Cooling Temperature setpoint used when in Standby mode.
AV42	Range : 54.0°F to 100.0°F (12.0°C to 37.5°C)
Occupied Cooling Setpoint	Occupied Cool Setpoint
Default value: 75 0°F (24 0°C)	Displays the Cooling Temperature setpoint used when in Occupied or Override mode.
Read Only	Display Readings : 54.0°F to 100.0°F (12.0°C to 37.5°C)
AV40	
Occupied Heating Setpoint	Occupied Heat Setpoint
72.0°F (22.0°C)	Displays the Heating Temperature setpoint used when in Occupied or Override mode.
Read Only AV39	Display Readings: 40.0°F to 90.0°F (4.5°C to 32.0°C)
Standby Heating Setpoint	Standby Heat Setpoint
Default value:	Displays the Heating Temperature setpoint used when in Unoccupied mode.
AV41	Range : 40.0°F to 90.0°F (4.5°C to 32.0°C)
Unoccupied Heating	Unoccupied Heat Setpoint
Setpoint Default value:	Displays the Heating Temperature setpoint used when in Unoccupied mode.
62.0°F (16.5°C) AV43	Range : 40.0°F to 90.0°F (4.5°C to 32.0°C)
Dehumidification Setpoint	Dehumidification Setpoint
Default value: 50% AV71	Displays the Dehumidification setpoint used when dehumidification is enabled.
	Range: 30% to 95%

Terminals



- Terminals will be shown with their usage, based on their configuration.
- Inputs will show the binary state, analog voltage or temperature based on their configuration.
- Outputs can be binary or analog outputs, and can be controlled by clicking on the output to access the corresponding Test Output page.

Digital Output



Parameter Default Value	Significance and Adjustments
Terminal Name	Terminal Name
Read Only	Displays the full name of this Digital Output.
	Display Pondings: Active Inactive
	Display Readings. Active, inactive
Terminal Usage	Terminal Usage
Read Only	The Terminal Usage is based on the current configuration of the Room Controller:
	 Native features include: DO1 Y1 Cool Y2 Cool W1 Heat W2 Heat Low Speed Fan Medium Speed Fan High Speed Fan Supply Temperature Sensor Filter Alarm Terminals under the control of BACnet/Lua can be customized
Terminal State	Terminal State
Read Only	Displays the status of this Digital Output relay:
	On: Relay closedOff: Relay open
	NOTE: For D6, the relay will be selected by the configured output type.
	Display Readings: Off, On

Parameter Default Value	Significance and Adjustments
Test Terminal	Test Terminal
Default value: Disabled	Used to disable/enable the verification of this Digital Output terminal. If enabled, it allows the user to see the Test State feature.
	NOTES:
	 The test must be disabled when the user disables Test Terminal or when the Terminals screen is exited (user exit, timeout). The test is disabled when the (parent) Terminals screen is exited rather than the individual output page, to allow the test of two terminals in combination. In the case of an ECM fan, for example, it has a Digital Output to enable it, then an Analog Output to control the speed.
	Choices: Disabled, Enabled
Test State	Test State
Default value: Disabled	Used to disable/enable the verification of this Digital Output status. Test State is only visible if Test Terminal is set to enabled.
	Choices: Disabled, Enabled

User Management



Parameter Default Value	Significance and Adjustments
User List	Refer to "User List" on page 98 for more information.
Add User	Refer to "Add User" on page 100 for more information.
Settings	Refer to "Settings" on page 101 for more information.

User List



Parameter Default Value	Significance and Adjustments	
User List	Displays the list of available users on this Room Controller. Tapping on a name will open the User Info screen. Refer to "User Info" on page 99 for more information.	

User Info



PARAMETER DETAILS

NOTE: The Delete User button is only visible to Admin users.

Parameter Default Value	Significance and Adjustments
User ID Read Only	Active User Id
CSV31	
	Display Readings : 3 to 32 characters (a-z, A-Z, 0-9, @~+=^<>,.½:;*'`, and spaces)
Display Name Read Only	Display Name
	Displays the user screen name.
	Display Readings : 3 to 32 characters (a-z, A-Z, 0-9, @~+=^<>,.1/2:;*'`, and spaces)
Role	Role
Read Only	Technician: Access to HVAC and local Room Controller-related configuration, but not to IP, FWU etc.
	Admin: Full access to all screens and features.
	Display Readings: Technician, Admin

Add User

<	Add User	
	User ID	
	Display Name	
	Role Admin	~
	PIN	
		0
	Confirm PIN	
		0

Parameter Default Value	Significance and Adjustments			
User ID	Active User Id			
CSV31	Allows the user to enter a user name that is unique on this Room Controller.			
	Range: 3 to 32 characters (a-z, A-Z, 0-9, @~+=^<>,.½:;**`, and spaces)			
Display Name	Display Name			
	Allows the user to enter a screen name.			
	Range : 3 to 32 characters (a-z, A-Z, 0-9, @~+=^<>,.½:;*``, and spaces)			
Role	Role			
Default value: Technician	Technician: Access to HVAC and local Room Controller-related configuration, but not to IP, FWU etc.			
	Admin: Full access to all screens and features.			
	Choices: Technician, Admin			
PIN	PIN			
	Allows the user to create a unique protective access PIN.			
	The PIN can be up to a configurable number of 16 digits (PIN Minimum Length). Refer to "Settings" on page 101 for more information.			
	Range: 0 to 9999 (0-9)			
Confirm PIN	Confirm PIN			
	Allows the user to reenter the protective access PIN to confirm and complete the process.			
	The PIN can be up to a configurable number of 16 digits (PIN Minimum Length). Refer to "Settings" on page 101 for more information.			
	Range: 0 to 9999 (0-9)			

Settings



Parameter Default Value	Significance and Adjustments		
PIN Minimum Length	PIN Minimum Length		
Default value: 4	Sets the minimum number of characters required for user PINs.		
	Range: 4 to 16 characters		
Inactivity Timeout	Inactivity Timeout		
Delauit value: 5 Minutes	Sets the configurable period of inactivity (no touches of the screen) before the Room Controller automatically signs a user out.		
	Range: 1 to 60 Minutes		
Lock User After	Lock User After		
Default value: 5 Failed Logins	Sets the configurable number of consecutive unsuccessful login attempts before the Room Controller:		
	 Locks the user out for a configurable number of minutes defined in Lock User For. Notifies the user that they have been locked out and for how long. 		
	Range: 1 to 10 Failed Logins		
Lock User For	Lock User For		
Default value: 10 Minutes	Sets the configurable number of minutes during which a user is locked out after the number of consecutive unsuccessful login attempts defined in Lock User After. The Room Controller will notify the user when they have been locked out and for how long.		
	Range: 1 to 60 Minutes		

SECTION 4

Appendices

Appendix A: Terminal Correspondence

The terminals of a TRC6500 are identified differently and have a wider range of possible functions compared to those of any of the VT8650 Room Controllers. Nonetheless, there is a direct correspondence of functions between the terminals of the VT8650 and the TRC6500. Consult the table below to verify the appropriate terminal when replacing a VT8650 Room Controller with a TRC6500 Room Controller.

VT8650	VRC6500	
Terminal ID	Terminal ID	
BO1	D1	
Y2	D2	
Y1	D3	
G	D4	
RC	RC	
С	С	
RH	RH	
W1	D5	
W2-O/B	A1/D6	
Economizer	A2/D7	
Auxiliary Heat	A3/D8	
Dehumidifier	A4/D9	
RS485 +	RS485 +	
RS485 -	RS485 -	
RS485 REF	RS485 REF	
UI16	U1	
UI17	U2	
COM	СОМ	
UI19	U3	
UI20 (RS)	U4	
COM	СОМ	
UI22 (SAT)	U5	
UI23 (OAT)	U6	
UI24	U7	
	U8	

Appendix B: Cybersecurity Checklist

Physical Security

Security Screw

□ It is important to install the security screw on the bottom of the unit.

If this screw is not installed:

- The device could be stolen.
- An attacker could potentially access the RS-485 communication bus and
- perform unauthorized actions on the communication network.The device could be factory reset by an unauthorized person.

RS-485 Wiring (BACnet/MSTP and Modbus RTU)

BACnet/MSTP and Modbus RTU networks rely on the physical security of RS-485 wiring. It must therefore be installed behind physical barriers, so it is only accessible to authorized personnel.

An attacker with access to the RS-485 communication bus could potentially perform unauthorized actions on the communication network.

RS-485 wiring is present on the base board, so access must be limited to authorized personnel only. Install the security screw, as described in the previous section.

NOTICE

ACCESS TO RS-485 WIRING

Access to the RS-485 wiring of the BACnet/MSTP or Modbus/RTU network gives access to configure, upgrade, read logs or write files to the Touchscreen Room Controller. This must be restricted to authorized personnel only.

Failure to follow these instructions may lead to unauthorized users modifying the firmware or the configuration of the Room Controller.

Communication Networks

Disabled Unused Communication Networks

BACnet/MSTP and Modbus/RTU are disabled by default and should be left disabled on the Viconics Room Controller if they are not used.

BACnet and Modbus can be disabled in the Network menu for the Viconics Room Controller.

NOTICE

NOT A SECURITY SYSTEM

While the Viconics Room Controller supports various sensors (PIR Motion, Door/Window, Water Leak), any alarming or notifications are best effort only. The Viconics Room Controller is NOT a security system, and no guarantees are given that an alarm will be generated or delivered to the Building Management System (BMS) or higher-level systems.

Failure to follow these instructions may lead to system failure.

Networks

- □ IP networks should be carefully planned and managed to minimize risks:
 - Reference: Guidance on Implementing a Cybersecure BMS Architecture with EcoStruxure Building Operation.
 - Use VLANs and firewalls to separate networks.
 - Separate building control networks from networks or devices that:
 - Are critical systems.
 - Contain payment or private data.
 - Are publicly accessible (e.g., to guests or staff).
 - Limit or disable external access to building control networks.
- Viconics Room Controller

□ Recommendations:

- Wi-Fi is disabled by default and should only be enabled when required.
- Regularly update your Room Controller firmware to ensure the latest Wi-Fi security enhancements are in use.
- Viconics Room Controller supports the following security protocols:
 - WPA2-personal
 - WPA3-personal (Recommended).
- Viconics Room Controller does not support connecting to Wi-Fi networks using the following insecure security protocols:
 - No security
 - WEP
 - WPA
- When a Viconics Room Controller is removed from a Wi-Fi network, ensure all security material is removed by performing:
 - "Disconnect and forget" from the Wi-Fi menu, or
 - Factory reset:
 - Full factory reset via reset pin, or
 - Software factory reset via Device info menu, with `Network` selected.
- Wi-Fi can be disabled and re-enabled in the Network menu. Disabling Wi-Fi does not remove network information from the Viconics Room Controller.
- All wireless networks are vulnerable to interference and jamming, which can block or disrupt communication. Carefully consider if wireless communications are appropriate for your application.

BACnet/IP

- BACnet/IP relies on security of the IP network:
 - The device is intended to operate on a private IP network, without external connectivity, or protected by security aware device(s).
 - Use VLANs and firewalls to separate the BACnet/IP network.
 - Prevent access to the network by authorized people and devices by physically protecting IP cabling and managing wireless network access.
 - Monitor your network to check for unexpected devices or traffic.
 - Do not enable BACnet/IP on a public network.

NOTICE

UNAUTHORIZED ACCESS

It is very important to plan and manage the BACnet/IP network according to the above guidelines.

Failure to follow these instructions may lead to unintended access to the Room Controller.

Ping

Ping is a useful debugging tool for IP devices, but it can also be used by attackers to perform DDoS attacks to overwhelm a device and attempt to disable it.

To prevent or reduce ping attacks, it is recommended to:

- Use a firewall to shield your network from malicious or unnecessary network traffic.
- Block ICMP ping in your firewalls. This prevents pings from external devices entering your network.
- Add filters to your firewall or router to drop packets from unknown sources.
- Use network monitoring software to detect unusual traffic patterns on your network.

Zigbee

ZigBee is disabled by default and should only be enabled when required.

ZigBee sensors that are no longer used should be removed from the Viconics Room Controller.

ZigBee networks configured for "normal" security are vulnerable to sniffing attacks while Permit Join is active. Ensure Permit Join is only activated when necessary, then deactivate immediately afterwards.

All wireless networks are vulnerable to interference and jamming, which can block or disrupt communication. Carefully consider if wireless communications are appropriate for your application.

User Management

Best PracticesAccounts should not be shared between users. Unique accounts should be created for each user.

When a user is no longer needed (e.g., employee leaves), their account should be removed.

User accounts should be created with roles allowing the least privileges required to perform their tasks.

Roles	Administrator	Technician
Factory Reset via Menu	\checkmark	\otimes
General HVAC/device configuration	\checkmark	\checkmark
Lua – Enable remote device access	\checkmark	0
Manage users	\checkmark	0
Test terminals	\checkmark	\checkmark
USB access	\checkmark	0
View status/service information	\checkmark	\checkmark

Passwords should not be obvious or repeated on many devices.

Do not use 1234, or the street number of the site.

Segment devices by area, do not use the same passwords on all devices.

U Wipe screen after use to avoid fingerprints from password entry remaining on the screen.

Consider regional privacy requirements when creating user and display names, as user names will appear in event logs.

Ensure user names are unique to help ensure clear traceability. For example, avoid creating both "User1" and "User 1".

Regularly delete the account or downgrade the role of users who no longer need access to the device.

□ Update passwords regularly.

Other Scenarios

□ If shared accounts are used (e.g., for a maintenance team in a large hotel), shared accounts should not have Admin privileges.

Impacts of Shared/Common Passwords

- Shared accounts make it unclear who accessed the devices; if someone acts in bad faith, it is not possible to detect who it was.
- □ It is difficult to track who knows the common password, and hence when it should be changed.
- □ If the password is disclosed externally, all users of the shared account will be affected by the required password change.

Store Administrator Passwords Securely

If all administrator passwords are lost, then the device must be factory reset manually by holding the reset button while powering on the device.

For more information, refer to the Viconics Room Controller Installation Sheet.

Log Files

The Viconics Room Controller contains two log files:

- System Log: Status of the system, including any errors.
- Audit Log: Record of changes made to the system, and by whom.

If unexpected issues occur, log files should be reviewed to determine the cause.

NOTICE

CONFIDENTIAL DATA IN LOG FILES

Log files may contain private or confidential data:

- Encrypt log files before transmitting them.
- Ensure log files are removed when decommissioning devices.
- Failure to follow these instructions may lead to the unauthorized sharing of private or confidential information.

Firmware Updates

NOTICE

UNAUTHORIZED ACCESS

The Viconics Room Controller firmware should be updated regularly to ensure the latest security improvements are applied.

Failure to follow these instructions may result in unauthorized access to the device.

Lua

NOTICE

UNAUTHORIZED ACCESS

Lua scripts allow customization of the device behavior, but come with risks:

- Only use scripts that are required for your device or site.
- Only use scripts that you understand or are from a trusted source.
- Remove scripts that are no longer required.
- Check scripts contain only the code you need and meet the recommendations of the Lua4RC Programming Guide.
- Carefully review and test scripts before deploying to sites.

Lua scripts can read and write data points on remote BACnet devices:

- Interacting with remote devices increases the scope of the Lua script and hence the risk of unintended behavior.
- Lua access to remote devices is disabled by default. If required, Remote Device Access must be enabled by an Admin in the Lua/Status menu.
- Lua access to remote devices should only be enabled if required.

Excessive writing of non-volatile priority levels may wear out the device's EEPROM memory. Refer to the <u>Lua4RC Programming</u>. <u>Guide</u> for more information.

Failure to follow these instructions may result in poorly-written or malicious Lua scripts, which may damage the device or result in unintended behavior.

Decommissioning

To decommission a device:

- 1. Factory reset:
 - Launch a factory reset to remove all data:
 - a. Log in as an administrator.
 - b. Tap on Device Info, then Factory Reset, ensuring all categories are selected.
 - Or perform a physical factory reset by holding the reset button while powering on the device. For more information, refer to the <u>Viconics Room Controller Installation Sheet</u>.
- 2. Refer to the End-of-Life Instruction (EoLi) document for information on how to recycle or dispose of the product.

NOTICE

DECOMMISSIONING A DEVICE

It is important to decommission a device properly to ensure that no confidential data is left on it.

Failure to follow these instructions may lead to the unauthorized sharing of private or confidential information.

Reporting an Incident or Vulnerability

Please report any cybersecurity incident or vulnerability via the Cybersecurity Support Portal on www.viconics.com.

The Schneider Electric Security Operations Center (SOC) operates 24 hours a day, 7 days a week, year-round, and is staffed with security analysts who receive and triage your reports.
Appendix C: Standby Screen



The Room Controller supports the display of a standby screen with a full screen image supplied by the user, which can be loaded via: USB or BACnet.

The Standby Screen is enabled when a custom image is selected via the Preferences/Display menu, or on BACnet:

- Use Standby Screen:
 - BACnet ID = MV32
 - 1=Disabled (Default)
 - 2=Custom Image

Size and format:

.

- Resolution: 480 x 800 pixels
- File format: 24-bit bitmap (.bmp)

The text overlay has 3 properties:

- Custom Standby Heading Text
- BACnet ID = CSV41
- Maximum length: 64 characters
- · Value: Input Characters: En ISO-8859-1 (Western Europe) character set glish
- Displayed if string is not empty
- Custom Standby Body Text
 - BACnet ID = CSV42
 - Maximum length: 160 characters
 - Value: Input Characters: ISO-8859-1 (Western Europe) character set
 - Displayed if string is not empty
- Custom Standby Text Color
 - BACnet ID = MV190
 - 1=White (Default)
 - 2=Black

Appendix D: Notifications



The Room Controller supports the option of displaying custom notifications on the screen.

PARAMETER DETAILS

Parameter Default Value	Significance and Adjustments
Short Screen Message Text CSV1	Short Screen Message Text
	Allows the user to enter a message on this Room Controller. Settable via BACnet only.
	Range : 0 to 160 characters (a-z, A-Z, 0-9, @~+=^<>,.½:;*'`, and spaces)
Notification Type	Notification Type
Default value: Disabled MV186	Used to configure the display of the notifications banner on the top of the screen. Settable via BACnet only:
	 Disabled: Critical: Red banner Warning: Yellow banner Ok: Green banner Informative: Blue banner
	Display Readings: 1=Disabled, 2=Critical, 3=Warning, 4=Ok, 5=Informative
Notifications	Notification Display Type
MV187	Used to configure the display of notifications on screen. Refer to "Display" on page 78 for more information:
	 Disabled: No notifications shown. Custom Only: Custom notifications shown, but no In-built notifications. All: Custom and in built notifications shown.
	Display Readings: 1=Disabled, 2=Custom Only, 3=All